

Use to set your desired temperature. Temperature levels range from “Warm” up to 450°F and include a Broil/Toasting setting.

The Power Light will illuminate when the Timer Dial is set, indicating that the appliance is on.

Use to set desired time for all functions. The Timer Dial goes up to 60 minutes. The toast icons represent different toasting levels from lightly toasted to well done.


NOTE: To set a time under 20 minutes, turn the Timer Dial up to 20 to begin cooking, then down to your desired time.


Use to turn the Rotating Basket on or off.

The interior light will illuminate when the oven is turned on.




Use the Function Dial to set your desired cooking method.






1. Put the Air Fry Basket on the Oven Rack in Position 2.
2. Set the Function Dial to Air Fry.
3. Set the Temperature Dial to preferred temperature.
4. Turn the Timer Dial to select cooking time - oven will begin air frying.
5. The timer will ring once when the cycle is complete and the oven will power off.


For items that may drip, such as meat or spring rolls, place the Air Fry Basket on top of the Baking Pan and Oven Rack, all in Position 1. This will prevent drips on the heating element.



1. Place the Baking Pan on the Oven Rack in Position 1.
2. Set the Function Dial to Bake.
3. Set the Temperature Dial to preferred temperature. Convection baking is faster than baking. Check food periodically to prevent overcooking.
4. Turn the Timer Dial to select cooking time — the oven will begin heating.
5. We recommend preheating the oven for 5 minutes prior to baking. Add this on to your baking time.
6. The timer will ring once when the cycle is complete and the oven will power off.



1. Put the Air Fry Basket and Baking Pan on the Oven Rack in Position 1.
2. Set the Function Dial to Broil.
3. Set the Temperature Dial to Toast/Broil.
4. Turn the On/Timer Dial to select cooking time — the oven will begin broiling.
5. The Timer will ring once when the cycle is complete and the oven will power off.




1. Place food inside Rotating Basket and snap door closed.
2. Secure the left side of the Rotating Basket to the gear on the interior side of the Air Fryer Oven first and then place the right side into the hook.
3. Close the door of the Air Fryer Oven and set the Function Dial to Air Fry. Set the Temperature Dial to the correct temperature.
4. Then, turn the Timer Dial to the desired cooking time to begin air frying.
5. Press the Rotate On/Off Button. You will see the basket begin to rotate. If not, turn the timer to OFF and re-adjust the gear alignment.

Be careful if you need to re-adjust the basket, as the heating element, oven and basket may be hot.


6. When finished, use the Removal Tool to hook underneath the basket arms and lift up and out. Place the basket on a heat-resistant surface to cool.

ALWAYS use the Removal Tool and kitchen gloves to remove the Rotating Basket.

7. Let the basket sit for a few minutes before opening the basket and removing cooked food.



1. Place the Oven Rack in Position 2.
2. Set the Function Dial to Toast.
3. Turn the Timer Dial up to 20 minutes to begin cooking, then down to your preferred shade setting. The Power Light will turn on.
4. When the toast cycle is complete, the timer will ring and the oven will power off.



1. Place the Baking Pan on the Oven Rack in position 1.
2. Set the Function Dial to Warm.
3. Set the Temperature Dial to Warm.
4. Turn the Timer Dial to select warming time — the oven will begin warming.
5. The timer will ring once the cycle is complete and the oven will power off.



Do not put the Air Fry Basket or the Baking Pan directly on the bottom heating element.

Before cooking, place the Drip Tray at the bottom of the Air Fryer Oven, below the heating element.

If you need to stop the Air Fryer Oven before the time elapses, turn the Timer Dial to OFF.

Be careful when removing/inserting the Drip Tray so that it does not scrape against the heating element. This could damage the heating element.

It is normal to see some moisture on the oven door during certain cooking cycles.

When air frying, food can be lightly sprayed with oil to boost crispness and browning. You can use a sprayer or toss the food in a plastic bag with some oil. Remove food from plastic bag before cooking.

Larger items, like chicken cutlets, should be flipped halfway through the cooking process to ensure even cooking. A large quantity of items, like fries, can be shaken halfway through air frying to ensure even cooking. Opening the 10L Air Fryer Oven to flip or shake food will not disrupt the cooking process.

The Oven Light turns on only when the oven is in use and the door is closed.



Do not throw away.
Read before operating your Dash 10L Compact Air Fryer Oven.
Keep for future reference.

These helpful hints are intended to be a supplement to the Instruction Manual. In order to ensure safe operation and optimum performance, please read the entire Instruction Manual.

For more helpful hints, see the Instruction Manual.