


# **Rogue**

## **ET 201iP PRO**



## **Instruction manual**

TABLE OF CONTENTS

---

<b>1</b>	<b>SAFETY</b> .....	<b>3</b>
1.1	Meaning of symbols .....	3
1.2	Safety precautions .....	3
1.3	California proposition 65 warning .....	6
<b>2</b>	<b>INTRODUCTION</b> .....	<b>7</b>
2.1	Equipment .....	7
<b>3</b>	<b>TECHNICAL DATA</b> .....	<b>8</b>
<b>4</b>	<b>INSTALLATION</b> .....	<b>10</b>
4.1	Location .....	10
4.2	Lifting instructions .....	10
4.3	Mains supply .....	11
<b>5</b>	<b>OPERATION</b> .....	<b>13</b>
5.1	Connections and control devices .....	13
5.2	Connecting welding and return cables .....	13
5.3	Turning the power on/off .....	14
5.4	Fan control .....	14
5.5	Thermal protection .....	14
5.6	Functions and symbols .....	14
5.7	Setting panel .....	16
5.8	Remote control .....	17
<b>6</b>	<b>MAINTENANCE</b> .....	<b>18</b>
6.1	Routine maintenance .....	18
6.2	Cleaning the power source .....	18
<b>7</b>	<b>TROUBLESHOOTING</b> .....	<b>20</b>
<b>8</b>	<b>ORDERING SPARE PARTS</b> .....	<b>21</b>
	<b>DIAGRAM</b> .....	<b>22</b>
	<b>ORDERING NUMBERS</b> .....	<b>23</b>
	<b>ACCESSORIES</b> .....	<b>24</b>

# 1 SAFETY

## 1.1 Meaning of symbols

As used throughout this manual: Means Attention! Be Alert!

**DANGER!**

Means immediate hazards which, if not avoided, will result in immediate, serious personal injury or loss of life.

**WARNING!**

Means potential hazards which could result in personal injury or loss of life.

**CAUTION!**

Means hazards which could result in minor personal injury.

**WARNING!**

Before use, read and understand the instruction manual and follow all labels, employer's safety practices and Safety Data Sheets (SDSs).



## 1.2 Safety precautions

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
  - its operation
  - location of emergency stops
  - its function
  - relevant safety precautions
  - welding and cutting or other applicable operation of the equipment
2. The operator must ensure that:
  - no unauthorized person is stationed within the working area of the equipment when it is started up
  - no-one is unprotected when the arc is struck or work is started with the equipment
3. The workplace must:
  - be suitable for the purpose
  - be free from drafts
4. Personal safety equipment:
  - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves
  - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns

5. General precautions:

- Make sure the return cable is connected securely
- Work on high voltage equipment **may only be carried out by a qualified electrician**
- Appropriate fire extinguishing equipment must be clearly marked and close at hand
- Lubrication and maintenance must **not** be carried out on the equipment during operation

**If equipped with ESAB cooler**

Use ESAB approved coolant only. Non-approved coolant might damage the equipment and jeopardize product safety. In case of such damage, all warranty undertakings from ESAB cease to apply.

For ordering information, see the "ACCESSORIES" chapter in the instruction manual.



**WARNING!**

Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting.



**ELECTRIC SHOCK - Can kill**

- Install and ground the unit in accordance with instruction manual.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from work and ground.
- Ensure your working position is safe



**ELECTRIC AND MAGNETIC FIELDS - Can be dangerous to health**

- Welders with pacemakers should consult their physician before welding. EMF may interfere with some pacemakers.
- Exposure to EMF may have other health effects which are unknown.
- Welders should use the following procedures to minimize exposure to EMF:
  - Route the electrode and work cables together on the same side of your body. Secure them with tape when possible. Do not place your body between the torch and work cables. Never coil the torch or work cable around your body. Keep welding power source and cables as far away from your body as possible.
  - Connect the work cable to the workpiece as close as possible to the area being welded.



**FUMES AND GASES - Can be dangerous to health**

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.



**ARC RAYS - Can injure eyes and burn skin**

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.



**NOISE - Excessive noise can damage hearing**

Protect your ears. Use earmuffs or other hearing protection.

**MOVING PARTS - Can cause injuries**



- Keep all doors, panels, guards, and covers closed and securely in place.
- Have only qualified people remove covers for maintenance and troubleshooting as necessary.



- Keep hands, hair, loose clothing and tools away from moving parts.
- Reinstall panels or covers and close doors when service is finished and before starting the unit.

**FIRE HAZARD**



- Sparks (spatter) can cause fire. Make sure that there are no inflammable materials nearby.
- Do not use on closed containers.

**HOT SURFACE - Parts can burn**



- Do not touch parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or insulated welding gloves to prevent burns.



**CAUTION!**

This product is solely intended for arc welding.



**WARNING!**

Do not use the power source for thawing frozen pipes.



**CAUTION!**

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.



**NOTE!**

**Dispose of electronic equipment at the recycling facility!**

To conform with the European Directive 2012/19/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.



**ESAB has an assortment of welding accessories and personal protection equipment for purchase. For ordering information contact your local ESAB dealer or visit us on our website.**

## 1.3 California proposition 65 warning



**WARNING!**

Welding or cutting equipment produces fumes or gases which contain chemicals known in the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)



**WARNING!**

This product can expose you to chemicals including lead, which are known to the state of California to cause cancer and birth defects or other reproductive harm. Wash hands after use.

For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## 2 INTRODUCTION

---

**Rogue ET 201iP PRO** is an inverter-based power source intended for MMA / SMAW / Stick, MMA pulse, TIG / GTAW, TIG pulse, and HF TIG welding.

**ESAB accessories for the product can be found in the "ACCESSORIES" chapter of this manual.**

### 2.1 Equipment

**Rogue ET 201iP PRO** includes:

- Power source
- Work clamp leadset, 6 AWG (0.63 in<sup>2</sup>), 9.84 ft
- Electrode holder leadset, 6 AWG (0.63 in<sup>2</sup>), 9.84 ft
- TIG torch and accessories kit
- Gas hose, 13.12 ft
- Gas regulator
- Power adapter (120 V–230 V)
- Instruction manual
- Quick start guide

## 3 TECHNICAL DATA

<b>Rogue ET 201iP PRO</b>		
<b>Outlet voltage</b>	230 V $\pm$ 15% 1~ 50/60 Hz	120 V $\pm$ 15% 1~ 50/60 Hz
<b>Primary current</b>		
$I_{max}$ MMA / Stick / SMAW	30 A	25.7 A
$I_{max}$ TIG / GTAW	19.5 A	24 A
<b>No-load power</b> demand when in energy-saving mode	50 W	50 W
<b>Setting range</b>		
MMA / Stick / SMAW	20-200 A	20-110 A
TIG / GTAW	10-200 A	10-140 A
<b>Permissible load at MMA / Stick / SMAW</b>		
25% duty cycle	200 A / 28 V	110 A / 24.4 V
60% duty cycle	129 A / 25.2 V	70 A / 22.8 V
100% duty cycle	100 A / 24 V	55 A / 22.2 V
<b>Permissible load at TIG / GTAW</b>		
25% duty cycle	200 A / 18 V	140 A / 15.6 V
60% duty cycle	129 A / 15.2 V	90 A / 13.6 V
100% duty cycle	100 A / 14 V	70 A / 12.8 V
<b>Apparent power <math>I_2</math></b> at maximum current	6.9 kVA	3.3 kVA
<b>Active power <math>I_2</math></b> at maximum current	6.8 kW	3.26 kW
<b>Power factor</b> at maximum current		
TIG / GTAW	0.99	0.99
MMA / Stick / SMAW	0.99	0.99
<b>Efficiency</b> at maximum current		
MMA / Stick / SMAW	82%	85%
TIG / GTAW	82%	85%
<b>Open-circuit voltage <math>U_0</math> max</b>		
VRD 35 V deactivated	78 V	78 V
VRD 35 V activated	<30 V	<30 V
<b>Operating temperature</b>	-10 to +40 °C (+14 to 104 °F)	-10 to +40 °C (+14 to 104 °F)
<b>Transportation temperature</b>	-20 to +55 °C (-4 to +131 °F)	-20 to +55 °C (-4 to +131 °F)
<b>Continual sound pressure at no-load</b>	<70 dB	<70 dB

<b>Rogue ET 201iP PRO</b>	
<b>Dimensions l × w × h</b>	403 × 153 × 264 mm (15.9 × 6 × 10.4 in.)
<b>Weight</b>	9.6 kg
<b>Insulation class transformer</b>	F
<b>Enclosure class</b>	IP23S
<b>Application class</b>	<b>S</b>

**Mains supply,  $S_{sc\ min}$** 

Minimum short circuit power on the network in accordance with IEC 61000-3-12.

**Duty cycle**

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 104 °F/ 40 °C, or below.

**Enclosure class**

The **IP** code indicates the enclosure class, i.e. the degree of protection against penetration by solid objects or water.

Equipment marked **IP23S** is intended for indoor and outdoor use; however, should not be operated in precipitation.

**Application class**

The symbol **S** indicates that the power source is designed for use in areas with increased electrical hazard.

---

## 4 INSTALLATION

---

The installation must be carried out by a professional.




**CAUTION!**

This product is intended for industrial use. In a domestic environment this product may cause radio interference. It is the user's responsibility to take adequate precautions.

### 4.1 Location

Position the power source so that cooling air inlets and outlets are not obstructed.



A. Minimum 200 mm (8 in.)

B. Minimum 200 mm (8 in.)



**WARNING!**

Secure the equipment - particularly if the ground is uneven or sloping.

### 4.2 Lifting instructions

These units are equipped with a handle for carrying purposes.



**WARNING!**


Electric shock can kill. Do not touch live electrical parts. Disconnect the input power conductors from the de-energized supply line before moving the welding power source.



**WARNING!**

Falling equipment can cause serious personal injury and equipment damage.

Lift the unit with the handle on top of the case.



### 4.3 Mains supply




**NOTE!**

**Rogue ET 201iP PRO** complies with IEC 61000-3-12 provided that the short-circuit power is greater than or equal to  $S_{scmin}$  at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power greater than or equal to  $S_{scmin}$ . Refer to the technical data in the TECHNICAL DATA chapter.

The power source will automatically adjust to the supplied input voltage. Make sure that it is protected by the correct fuse rating. A protective ground connection must be made, in accordance with regulations.

1. Rating plate with supply connection data.



Recommended fuse sizes and minimum cable area for the ET 201iP PRO		
Supply voltage	230 VAC	120 VAC
Electrical cable area	14 AWG, 0.79 in <sup>2</sup>	14 AWG, 0.79 in <sup>2</sup>
Maximal current rating $I_{max}$ MMA / SMAW / Stick	30 A	25.7 A
$I_{1eff}$ MMA / SMAW / Stick	15 A	14.5 A

Recommended fuse sizes and minimum cable area for the ET 201iP PRO		
Fuse anti-surge type D MCB	20 A	20 A
Maximum recommended extension cord length	328.08 ft	328.08 ft
Minimum recommended extension cord size	12 AWG, 0.13 in <sup>2</sup>	12 AWG, 0.13 in <sup>2</sup>

**NOTE!**

Different variants of **Rogue ET 201iP PRO** are certified for different outlet voltages. Always refer to the rating plate for the specification of the power source in use.

**NOTE!**

Use the power source in accordance with the relevant national regulations.

**Supply from power generators**

The power source can be supplied from different types of generators. However, some generators may not provide sufficient power for the welding power source to operate correctly. Generators with Automatic Voltage Regulation (AVR) or with equivalent or better type of regulation, with 7 kW rated power, are recommended.

## 5 OPERATION

General safety regulations for handling the equipment can be found in the "SAFETY" chapter of this manual. Read it through before you start using the equipment!



### NOTE!


When moving the equipment use intended handle. Never pull the cables.



### WARNING!

Electric shock! Do not touch the workpiece or the welding head during operation!

### 5.1 Connections and control devices



- |                              |                                      |
|------------------------------|--------------------------------------|
| 1. Setting panel             | 5. Mains power supply switch, I/O    |
| 2. Positive welding terminal | 6. TIG / GTAW switch / Remote socket |
| 3. Negative welding terminal | 7. Gas supply output                 |
| 4. Power cable               | 8. Gas supply input                  |

### 5.2 Connecting welding and return cables

The power source has two outputs, a positive welding terminal (+) and a negative welding terminal (-), for connecting welding and return cables. The output to which the welding cable is connected depends on the welding method or type of electrode used.

- For TIG / GTAW welding, the negative welding terminal (-) is used for the welding torch and the positive welding terminal (+) is used for the return cable.
- For MMA / Stick / SMAW welding, the welding cable can be connected to the positive welding terminal (+) or negative welding terminal (-), depending on the type of electrode used. The connection polarity is stated on the electrode packaging.

- 1) Connect the return cable to the other output on the power source.

- 2) Secure the return cable's contact clamp to the workpiece, and make sure that there is a good contact between the workpiece and the output for the return cable on the power source.

### 5.3 Turning the power on/off



#### CAUTION!

Do not turn off the power source during welding (with load).

- 1) Turn on the power by turning the switch to the "ON" (I) position.
- 2) Turn the unit off by turning the switch to the "OFF" (O) position.

Whether the power supply is interrupted or the power source is switched off in the normal manner, weld programs are stored so that they are available the next time the unit is started.

### 5.4 Fan control

The **ET 201iP PRO** is fitted with a fan as needed feature. Fan-as-needed automatically switches the cooling fan off when it is not required. This has two main advantages; (1) to minimize power consumption, and (2) to minimize the amount of contaminants such as dust that are drawn into the power source.



#### NOTE!

The fan only operates when required for cooling purposes and automatically switches off when not required.

### 5.5 Thermal protection



The power source includes thermal protection against overheating. When overheating occurs, welding stops, the overheating indicator on the panel illuminates, and an error message appears on the display screen. The protection is automatically reset once the temperature has decreased to a safe level.

### 5.6 Functions and symbols



#### MMA / Stick / SMAW welding

MMA / Stick / SMAW welding may also be referred to as welding with coated electrodes. Striking the arc melts the electrode, and its coating forms protective slag.

For MMA / Stick / SMAW welding the power source shall be supplemented with:

- Welding cable with electrode holder
- Return cable with clamp

#### Arc force

**Arc Force** The arc force function determines how the current changes in response to variations in arc length during welding. Use a low value of arc force to get a calm arc with little spatter and use a high value to get a hot and digging arc.

Arc force only applies to MMA / Stick / SMAW welding.

**Hot start**

**Hot Start** The hot start function temporarily increases the current in the beginning of the weld. Use this function to reduce the risk of insufficient fusion as well as electrode sticking and scratching.

Hot start only applies to MMA / Stick / SMAW welding.

**TIG / GTAW welding**



TIG / GTAW welding melts the metal of the workpiece, an arc initiated from a non-consuming tungsten electrode. The weld pool and electrode are protected by shielding gas.

For TIG / GTAW welding, the welding power source shall be supplemented with:

- a TIG / GTAW torch with gas valve
- an argon gas cylinder
- an argon gas regulator
- tungsten electrode

This power source performs **LiftArc™ start**.

The tungsten electrode is placed against the workpiece and the trigger is pressed. When lifted away from workpiece the arc is struck at a limited current level. Release button to stop the arc.

**HF start**

The HF (High Frequency) start function strikes the arc by means of a spark from the tungsten electrode to the workpiece as the electrode is brought closer to the workpiece and the trigger on the TIG / GTAW torch is pressed.

**Voltage Reduction Device (VRD)**

The VRD function ensures that the open-circuit voltage does not exceed 35 V when welding is not being carried out. This is indicated by a lit VRD indicator on the panel. Contact an authorized ESAB service technician to activate this function.

**Pulse welding**


Pulse welding is a technique used primarily to improve the control of the weld pool and the solidification process and minimize the material distortion by reducing the heat input. The pulsing of the current gives the weld pool time to solidify at least partially between each pulse. In order to set up pulsed welding it is required to define the parameters: peak current, pulse frequency, and background current. Pulse frequency range is 0.2-100Hz at SMAW mode and 0.2-500Hz at GTAW mode.

**Trigger mode indicator**

The trigger mode control is used to switch the functionality of the torch trigger between 2-stroke (2T) and 4-stroke (4T) at TIG / GTAW mode.


**2T mode (2-stroke)**

2T mode (when trigger mode indicator not illuminated). In this mode, the torch trigger must remain depressed for the welding output to be active. Press and hold the torch trigger to activate the power source (weld). Release the torch trigger switch to cease welding.

**4T mode (4-stroke)**

4T mode (active when trigger mode indicator illuminated). This mode of welding is mainly used for long welding runs to reduce operator fatigue. In this mode the operator can press and release the torch trigger and the output will remain active. To deactivate the power source, the trigger switch must again be depressed and released, thus eliminating the need for the operator to hold the torch trigger.

## 5.7 Setting panel



- |  |   |
|--|---|
| 1. Overheating indicator                                 | 7. Options button   |
| 2. Display   | 8. Welding current control knob and advanced feature control knob |
| 3. VRD function (reduced open-circuit voltage) indicator | 9. Process selection button                                       |
| 4. Trigger mode indicator                                | 10. MMA / Stick / SMAW indicator                                  |
| 5. Pulse mode indicator                                  | 11. GTAW LiftArc™ indicator                                       |
| 6. Frequency indicator                                   | 12. GTAW HF indicator   |

**Process selection button (9):**

- GTAW HF (12)
- GTAW LiftArc™ (11)
- MMA / Stick / SMAW (10)
- Navigation
- Parameter selection

Press the Process selection button (9) for 3 sec to go to the advanced feature menu and press the Process selection button (9) to select the values.

**Control knob (8):**

To change the values.

**In GTAW HF or LiftArc™ mode:**

- Gas pre-flow time (PREG 0–5 s)
- Start current (IGNA 10–100%)
- Up slope time (SLPU 0–10 s)
- Down slope time (SLPD 0–10 s)
- End current (FINA 10–100%)
- Gas post-flow time (POSG 0.5–15 s)
- Background current (BKGA 10–100%)

### In MMA / Stick / SMAW:

- Background current (BKGA 60-80%)
- Hot start (HOTS -10 – +10)
- Arc force (ARCF -10 – +10)
- Cellulose electrode (CELL On/Off)

### Options button (7):

Press the Options button (7) to set the following:

- Trigger mode (4): 2 stroke / 4 stroke.
- Pulse mode (5): (On / Off).
- Frequency (6): 0.2-100Hz at MMA / Stick / SMAW process or 0.2-500Hz at TIG / GTAW process) – only if Pulse mode is ON.

## 5.8 Remote control

Connect the remote control to the front of the power source. When the remote control is connected, it is automatically activated. The maximum setting of the power source will be determined by the respective front panel control, irrespective of the remote control device setting.

## 6 MAINTENANCE

**WARNING!**

The mains supply must be disconnected during cleaning and maintenance.

**CAUTION!**

Only persons with appropriate electrical knowledge (authorized personnel) may remove the safety plates.

**CAUTION!**

The product is covered by manufacturer's warranty. Any attempt to carry out repair work by non-authorized service centers or personnel will invalidate the warranty.

**NOTE!**

Regular maintenance is important for safe and reliable operation.

**NOTE!**





Perform maintenance more often during severe dusty conditions.

Before each use, make sure that the:

- Product and cables are undamaged, and
- The torch is clean and undamaged.

### 6.1 Routine maintenance

Maintenance schedule during normal conditions. Check equipment before every use.

Interval	Area to maintain		
Every 3 months	 Clean or replace unreadable labels.	 Clean weld terminals.	 Check or replace weld cables.
Every 6 months	 Clean inside equipment. Use dry compressed air with reduced pressure.		

### 6.2 Cleaning the power source

To maintain the performance and increase the lifetime of the power source, it is mandatory to clean it regularly. How often depends on:

- The welding process
- The arc time

- The working environment



**CAUTION!**

Make sure that the cleaning procedure is done in a suitable prepared workspace.



**CAUTION!**

During cleaning, always wear recommended personal safety equipment, such as ear plugs, safety glasses, masks, gloves, and safety shoes.

- 1) Disconnect the power source from the power supply.
- 2) Open the enclosure and use a vacuum cleaner to remove any accumulated dirt, metal filings, slag and loose material. Keep the shunt and lead screw surfaces clean as accumulated foreign material may reduce the welder's output welding current.

## 7 TROUBLESHOOTING

Perform these checks and inspections before sending for an authorized service technician.

- Check that power is disconnected before starting any type of repair action.

Type of fault	Corrective action
MMA / SMAW / Stick welding problems	Check the welding process is set for MMA / SMAW / Stick.
	Check that the welding and return cables are correctly connected to the power source.
	Make sure that the return clamp has good contact with the workpiece.
	Check that the correct electrodes and polarity are being used. For polarity, check electrode packaging.
	Check that the correct Welding current (A) is set.
	Adjust Arc Force and Hot start.
TIG / GTAW welding problems	Check the welding process is set for LiftArc™ TIG / GTAW as necessary.
	Check that the TIG / GTAW torch and return cables are correctly connected to the power source.
	Make sure that the return clamp has good contact with the workpiece.
	Make sure that the TIG / GTAW torch lead is connected to the negative welding terminal.
	Make sure that the correct shielding gas, gas flow, welding current, filler rod placement, electrode diameter and welding mode on power source is used.
No arc	Check that the electrical power supply switch is turned on.
	Check that the display is on to verify that the power source has power.
	Check that the setting panel is displaying correct values.
	Check that welding and return cables are correctly connected.
	Check the electrical power supply fuses.
Welding current is interrupted during welding	Check whether the Over Temperature LED (Thermal Protection) on the setting panel is on.
	Continue with Troubleshooting "No Arc".
The thermal protection trips frequently	Make sure that the recommended duty cycle for the weld current has not been exceeded.
	Refer to power source "Duty cycle" in Section 3 "Technical data", page 9.
	Make sure that the air inlets or outlets are not clogged.
	Clean the inside of the machine using routine maintenance methods.

## 8 ORDERING SPARE PARTS

---



**CAUTION!**

Repair and electrical work should be performed by an authorized ESAB service technician.  
Use only ESAB original spare and wear parts.


The **Rogue ET 201iP PRO** is designed and tested in accordance with the international and North American standards **CSA E60974-1** and **ANSI/IEC 60974-1**. On completion of service or repair work, it is the responsibility of the person(s) performing the work to ensure that the product still complies with the requirements of the above standards.

Spare parts and wear parts can be ordered through your nearest ESAB dealer, see [esab.com](https://www.esab.com). When ordering, please state product type, serial number, designation and spare part number in accordance with the spare parts list. This facilitates dispatch and ensures correct delivery.


# APPENDIX

## DIAGRAM

From serial number HA430-xxxx-xxxx



## ORDERING NUMBERS










Ordering number	Denomination	Type	Notes
0705 002 023	Power source	Rogue ET 201iP PRO	NAM
0448 683 *	Instruction manual		

The three last digits in the document number of the manual show the version of the manual. Therefore they are replaced with \* here. Make sure to use a manual with a serial number or software version that corresponds with the product, see the front page of the manual.

Technical documentation is available on the Internet at: [www.esab.com](http://www.esab.com)

## ACCESSORIES

TIG torches		
0700 026 636	TIG torch, SR-26, 4 m, remote	
0700 026 637	TIG torch, SR-26, 8 m, remote	
0700 026 638	Accessory kit, torch 17/26	
WS200E13	Electrode holder, 200 A and lead assembly, 4 m, 50 mm	
WS200G10	Ground clamp, 200 A and lead assembly, 3 m, 50 mm	
0781-2701 GRF400-580	Regulator flow meter	
W4014000	Power adapter	
0700 500 086	Shoulder strap	
W4014450	Foot pedal, 8-pin	





# A WORLD OF PRODUCTS AND SOLUTIONS.



For contact information visit <http://esab.com>

ESAB Corporation, 2800 Airport Road Denton, TX 76207, USA, Phone +1 800 378 8123

[manuals.esab.com](http://manuals.esab.com)

