



SKU # 1007 581 047
Model # 22RT5672235YX

ASSEMBLY INSTRUCTIONS

60IN SILHOUETTE CHRISTMAS STAR

141L WIRE TUBE LIGHTED

USE AND CARE GUIDE

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on the ground. Many parts are connected by the lighting string that runs throughout the item. Take special care not to pull, cut or damage the lighting string. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. It is recommended to assemble parts of the product while laying flat on the ground or table versus standing the item up to assemble the parts. If any parts are missing or damaged do not attempt assembly but contact our customer service center or return to place of purchase with purchase receipt.

Assembly of this product may require more than one person.
1-855-HDHoliday (1-855-434-6543)

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 14.4 Watts (0.12 Amps). Do not overload. Do not connect to another lighting string, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Discard or return to place of purchase with purchase receipt if the product has cuts, damage, frayed wire insulation on cords, cracks in the socket enclosures, loose connections, exposed copper wire or other obvious damage.

Care and Cleaning

- Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product connections, and wires. If the product is placed somewhere other than the ground it should be well secured, flat and stable.
- Carefully disassemble the unit taking caution not to cut any electrical wires.
- Wipe the unit with a damp cloth and allow the unit to dry before storing.
- Store the product neatly in a cool, dry location protected from sunlight.

Troubleshooting

- Ensure that the floor or surface that the item sits on is flat and level
- Be sure to plug the item correctly to a wall outlet or a UL Listed Power Cord
- Ensure all parts are assembled properly per the Instruction Manual
- If the item does not light check for loose or broken bulbs and connections
- Do not plug into other electrical items
- If the item has multiple Light String Cords be sure to plug in all cords
- Check for Broken or Burned Out Fuse In Plug


Guarantee

What is Covered

The product is intended for residential seasonal use for 90 days per year. This product is covered by a 90 days limited guarantee due to defects in material and workmanship. Return the product with purchase receipts to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse, in store display models or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday 1-855-HDHoliday (1-855-434-6543)



Thank you!


We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 60IN SILHOUETTE CHRISTMAS STAR 141L WIRE TUBE LIGHTED. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

1-855-HDHoliday (1-855-434-6543)
HOMEACCENTSHOLIDAY.COM

Parts List		
Locater	Name	Qty.
A	Upper Portion of Star	1
B	Lower Portion of Star	1
C	Base Stand	1
D	Support Bar	1

Hardware List		
Locater	Name	Qty.
E	Plastic Tie	10
F	Cotter Pin	4
G	Ground Stake	4


Diagram of Parts



ASSEMBLY


1 Assembling the Upper Portion to Lower Portion of Star

Place all the parts flat on the ground; Insert the connecting rods on the bottom of Upper Portion (A) into the connecting holes on the top of Lower Portion (B) and fasten at the connecting loops with Plastic Ties (E).



2 Assembling the Base Stand and Support Bar

Insert the connecting rods on the bottom of Lower Portion (B) into the matching holes of Base Stand (C) and fasten at connecting loops with Plastic Tie(E). Insert each hooked end of the Support Bar (D) into the matching hole of Upper Portion (A) and the Base Stand (C) respectively then secure with the Cotter Pins (F). The Support Bar (D) come with metal bars attached to stabilize the Star. Insert the hooked end of the metal bars into the metal nut on the Lower Portion (B).



3 Assembling the Ground Stakes

Place the 4 Ground Stakes (G) over the 4 Corners of the Base Stand then firmly into the ground.

