

AERO.BALL

CUSTOMS

You will need the following tools:

- 4mm Hex Bit + Driver
- 6.5mm Drill Bit + Drill
- 10mm Spanner
- Clamps
- Mounting Hardware



PRIOR TO THIS STEP YOU MAY NEED TO MOUNT THE FINS ONTO THE REAR DIFFUSER FIRST.

1. Place the pieces of the rear diffuser where they would be when mounted to get an idea of how you're going to mount it (different diffusers may vary). Use this opportunity to raise the car up in some way.



2. Clamp the piece of the rear diffuser onto the rear bumper of the car and align it appropriately.



Use this opportunity to adjust how far out you want the diffuser to sit past the bumper.



3. With the rear diffuser kept in place, use the 6.5mm drill bit to create holes for the mounting hardware. **SOME DIFFUSERS MAY ALREADY HAVE HOLES PRE-DRILLED FEEL FREE TO USE THOSE HOLES A GUIDE AS TO WHERE TO DRILL INTO THE REAR BUMPER.**



4. Thread through the bolts with the bigger washer on the side making contact with the diffuser and the smaller washer on the side making contact with the rear bumper. Thread on the nut by hand to keep them place for later.



5. Using the 4mm hex bit and the 10mm to keep the nut in place, mount the diffuser to the rear bumper. Ensure a snug but not too tight mount.



6. Now repeat this step with the rear pod pieces on the side (if the kit includes them). Some cars may need stock clips removed for a proper fit as pictured below.

