



FR

Cet appareil,
ses accessoires,
cordons et batteries
se recyclent

À DÉPOSER
EN MAGASIN

OU

À DÉPOSER
EN DÉCHÈTERIERECICLA
Al Amarillo

CE

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !



FR

MADE IN CHINA

ÉLÉMENTS D'EMBALLAGE
À SÉPARER ET À DÉPOSER
DANS LE BAC DE TRI

UK
CA

WARNING:

TO AVOID DANGER OF SUFFOCATION, KEEP THIS PLASTIC BAG
AWAY FROM BABIES AND CHILDREN. DO NOT USE THIS BAG IN CRIBS,
BEDS, CARRIAGES OR PLAY PENS. THIS BAG IS NOT A TOY.

⚠ Safety and Warnings

Read all instructions before use. Failure to follow these instructions may result in damage to the product or personal injury.

Warning: Keep the device and its cord out of reach of children under 3 years old.

Keep away from children unless supervised by an adult.

Do not use this product for purposes other than its intended use.

Inspect the product before each use; do not use if damaged.

Follow installation and operation guidelines to avoid injury.

Instructions for Use

1. Before First Use: Remove all protective films from the device.
2. Charging: Connect the provided USB cable to a certified 5V power adapter.
3. Operation: Press and hold the power button for 3 seconds to turn on the device. Short press the button to change modes.
4. After Use: Turn off the device and store it in a dry place. Keep away from children.

Product Name: Exerciser

Manufacturer: Dongguanshi hantongxi ndi anzi Co., Ltd.

Manufacturer Address: Room 301, Building 23, Changping Jewelry Cultural
Industry Center, No. 568 Huan Chang North Road, Changping Town, Dongguan
City, Guangdong Province

Telephone: 15024077469

Manufacturer E-mail: 1642518592@qq.com

EC REP

Name: ECLAT SOLUTION SARL

Address: PARIS Bureau 1145, 37 Passage du Ponceau,

France, PARIS E-mail: eclat solution@outlook.com