



User Manual

FERREX[®]

709075

15W GLUE GUN



<https://help.tools/>

Read all safety warnings and all instructions thoroughly before operating this product.

Ensure you keep your manual in a safe place for future reference.

IM ed 2; 07/2022

QR codes take you where you want to go quickly and easily

Whether you require product information, spare parts or accessories, details on warranties or aftersales service, or if you want to watch a product demonstration video, our QR codes will take you there in no time at all.

What is a QR code?

A QR-code (QR=Quick Response) is a type of matrix that can be read with a smartphone camera and that contains a link to a website or contact details, for example.

Advantage: You are not required to manually enter a website address or contact details.

How it works

To scan the QR code, all you need is a smartphone with QR codes reader software and an Internet connection*. This type of software can be downloaded for free from your smartphone's app store.

Try it out now

Just scan the QR code with your smartphone and find out more about the Aldi product you have purchased*.



* Depending on your tariff you may be charged for the connection.



FERREX®

15W Glue gun


Warranty details

REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration/ TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION.

The product is guaranteed to be free from defects in workmanship and parts for a period of 36 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AFTER SALES SUPPORT

 **1300 889 028**
(toll free)

e-mail: info.aldi@positecgroup.com
MODEL No.: PGG40G • 07/2022 • 709075



Contents

Pack contents /parts	2
Description of symbols	3
General safety warnings	4
Parts List	6
Assembly	7
Operation	8
Maintenance	10
Warranty	11
FAQ/Troubleshooting	12
Technical specifications	13

Pack contents / parts

Congratulations on the purchase of your FERREX® 15W Glue Gun. When you open your packaging, first remove all items and check there are no parts damaged or missing. If you find anything wrong, do not operate the product until the parts have been replaced or the fault has been rectified. Failure to do so could result in serious personal injury.

Application

First time users or inexperienced operators pay particular attention to the operation of the 15W Glue Gun, including details of starting and stopping and correct use of the 15W Glue Gun on pages 8-9, as well as the maintenance instructions on pages 10.

Intended use of 15W Glue Gun

NOTE: This product is for private domestic DIY use only. It is not suitable for commercial or trade use.

This 15W Glue Gun is used for the quick gluing of clean, dry and grease-free materials with glue heated to its melting point.

The glue gun is to be used only for its prescribed purpose. Any other use is deemed to be a case of misuse.

Contents of carton

- 1 x 15W Glue gun
- 20 x 100mm glue sticks
- 1 x Stand / rest
- 1 x Carry case
- 1 x Instruction manual
- 1 x Warranty Card

Description of symbols

Description of symbols

The instruction manual or rating plate on your product may show symbols. These represent important information about the product or instructions on its use.



To reduce the risk of injury, user must read instruction manual



Wear ear protection

Wear eye protection

Wear breathing protection



Conforms to relevant standards for electrical safety and electromagnetic compatibility.



Double insulation



36 Month Warranty Period.



The box is recyclable at kerbside.

General safety warnings

General power tool safety warnings



WARNING! Read all safety warnings and all instructions.

Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Additional safety warnings for your glue gun

1. Before connecting the unit to the mains - ensure the unit is switched OFF because it will achieve maximum heat in a little time.
2. Always wear protective gloves and eyewear because it can reach 83°C(+/-2%) Centigrade
3. **Always place the appliance on its stand after use and allow it to cool down before storage** and never touch the heat deflector.
4. Never attempt to use the appliance to dry animals, clothing or hair.
5. Never use this appliance as a hair dryer.
6. **Be aware that heat may be conducted to combustible materials that are out of sight.**
7. **Be careful When using this appliance in places where there are combustible materials** or gases, extreme caution must be taken to prevent fire or explosion.
8. **Do not apply to the same place for a long time.**

- 9. Do not use in presence of an explosive atmosphere. Always use it in ventilated areas.**
- 10. Do not leave the heat gun unattended when it is switched on.**
11. The appliance is not to be stored or left outdoors
12. This product is designed for light domestic use only, it is not designed for commercial, industrial or trade purposes.

Parts List

1. Nozzle with heat guard
2. Glue stick
3. Handle
4. Power cord
5. Flow control trigger
6. Support Stand / rest
7. 20 x Glue sticks
8. Glue stick entry





WARNING! Please read and understand this instruction manual before use and keep it for your future reference. Your glue gun should only be passed on together with this instruction manual.

Assembly

Installing a glue stick (see fig. A)



WARNING. Disconnect the glue gun from the mains power supply before making any adjustments or undertaking maintenance procedures.

1. Insert the provided glue stick (2) into the glue stick entry (8).
2. Squeeze the flow control trigger (5) multiple times to allow the glue stick (2) to be pushed down.




Operation

1. Switching on/off (see fig. B)

To put into operation

- 1) Insert the power plug into the mains power supply, and then press the flow control trigger (5).
- 2) Place the gun on the support stand / rest (6). Allow the gun to heat up for approximately 3 min before beginning work.



To switch off, release the flow control trigger (5) and pull the mains plug out.

⚠ WARNING: Allow the unit to cool completely before storing. The hot nozzle can cause damage.

NOTE: As the result of heat storage, the glue gun can also be used after it has heated up without being connected to the mains. If the glue that emerges becomes thick, insert the plug into the mains power supply again.

⚠ WARNING: Disconnect the glue gun from the mains power supply when not in use.

2. Gluing

Preparations for Gluing

The surfaces to be glued must be clean, dry and free of grease. A smoother surface is also more ideal for gluing.


⚠ WARNING: Do not use inflammable solvents for cleaning!

The ambient temperature and the work piece to be glued must not be cooler than +5 °C or warmer than +50 °C.

Warm rapidly cooling materials (e.g. steel) for better adhesion.

Gluing

- 1) Press the flow control trigger (5).
- 2) Apply the glue in dots around the edges of the workpiece surface. For gluing flexible materials (e.g. textiles), apply the glue in a zig-zag line.

 **Danger of burning!** The glue and the nozzle tip are heated to 200 °C. Do not allow the hot glue to come into contact with persons or animals. If hot glue touches the skin, immediately hold the spot for several minutes under a stream of cold water, and seek medical advice. Do not try to remove the glue from the skin.

- 3) After applying the glue, press the surfaces to be glued together immediately for a stronger bond.
- 4) Press the glued surfaces together for approximately 30 seconds. To assist with adhesion, apply a weighted load or clamp to the glued junction for approximately 5 minutes.
- 5) Between individual gluing actions, place the gun on the support stand / rest (6) .
- 6) Remove glue residue after cooling with a sharp knife. The glued junction can be separated again by heating. The glued junction can be painted.

 **WARNING: Do not place the heated glue gun on the support stand or have the nozzle pointed downwards for a long period of time when using! The glue will continue to slowly flow from the nozzle!**

 **WARNING: The glue gun should be switched off and allowed to cool down after 12 hours continuous use.**

Maintenance



WARNING: Disconnect the glue gun from the mains power supply before making any adjustments or undertaking maintenance procedures.

Keep the glue stick clean to prevent impurities from clogging the nozzle. After the glue stick is inserted, do not pull it out from the gun. After heated, if the glue gun is not used for more than 15 minutes, turn off the power switch and disconnect from the mains power supply. Avoid using the glue gun in a humid environment, which may result in electric shock. Do not disassemble the glue gun by yourself. Never use water or chemical cleaners to clean your glue gun. Wipe it with a dry clean cloth. Always store your glue gun in a dry place. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Storage

Store in a secure, dry place out of the reach of children. Do not place other objects on the product.

Warranty

Your new FERREX® 15W Glue gun will more than satisfy your expectations. It has been manufactured under stringent FERREX® Quality Standards to meet superior performance criteria.

You will find your new FERREX® 15W Glue gun easy and safe to operate, and, with proper care, it will give you many years of dependable service.

CAUTION. Carefully read through this entire instruction manual before using your new FERREX® 15W Glue gun.

Take special care to heed the Cautions and Warnings.

Your FERREX® 15W Glue gun has many features that will make your job faster and easier. Safety, performance, and dependability have been given top priority in the development of this 15W Glue gun, making it easy to maintain and operate.

Use only FERREX® replacement parts for your product. Non-conforming parts or modifications made to parts will void your warranty.

Environmental protection



Recycle unwanted materials instead of disposing of them as waste.

All tools, hoses and packaging should be sorted, taken to the local recycling centre and disposed of in an environmentally safe way.

Dispose of used engine oil in a manner that is compatible with the environment.

We suggest you take it in a sealed container to your local service station for reclamation. Do not throw it in the trash or pour it into the earth.

What your 3 year warranty means

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly.

In the event of product failure within its intended use over the course of the first 3 years after the date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product please contact us via our after sales support services, details of which can be found in this manual and on the product itself.

After Sales Support TEL: 1300 889 028 or email: info.aldi@positecgroup.com

FAQ/Troubleshooting

Fault	Cause	Remedy
1. After power on for 5 min, the glue gun stays cool.	1.1 Damaged power switch / socket. 1.2 The heater is broken.	1.1 Change to another switch / socket. 1.2 Contact customer service.
2. The glue gun is not dispensing glue normally during use.	2.1 Check to see if the glue gun is cool. 2.2 The nozzle is blocked.	2.1 Follow the Remedy 1.1 and 1.2. 2.2 Contact customer service.

For other issues not covered in this chart, please call Customer Service on 1300 889 028.

Technical Specifications

Rated voltage	220-240V ~ 50Hz
Rated power input	15 W
Melting point	83°C(+/-2%)
Glue stick size	10.8- 11.8 mm
Glue stick length	100mm
Weight	0.20 kg
Product dimensions	165*30*150 mm

This 15W Glue gun complies with the following Standards:

Safety: IEC 60335-1
IEC 60335-2-45
AS/NZS 60335.1
AS/NZS 60335.2.45

EMC: EN 55014-1
EN 55014-2
EN 61000-3-2
EN 61000-3-3

This is a blank page

This is a blank page

This is a blank page



ALDI guarantees that our exclusive brand products are developed to our stringent quality specifications. If you are not entirely satisfied with this product, please return it to your nearest ALDI store, within 60 days from the date of purchase, for a full refund or replacement, or take advantage of our after sales support by calling the supplier's Customer Service Hotline.



Made in China

Ferrex® is a registered trademark of ALDI Stores

DISTRIBUTED BY:

ALDI STORES

1 SARGENTS ROAD

MINCHINBURY NSW 2770

www.aldi.com.au

AFTER SALES SUPPORT



1300 889 028 (toll free)

e-mail: info.aldi@positecgroup.com

MODEL: PGG40G • 07/2022 • 709075

3

YEAR WARRANTY