




R36S MANUAL

RGB 20S Instruction



Functional Description



Combination Key Description

Brightness Adjustment--R3 +UP/DOWN	
Save/Read Game	SELECT+L1/R1
Save Location	SELECT+UP/DOWN
Exit Game	SELECT+START
Enter ESTROARCH	SELECT +X/L3 +R3
Pause the game	SELECT+A
Restart the game	SELECT+B

Special Instruction

power on/off & memory card description

1. You must insert the system card into TF1-OS position before starting up, then press the power key to power on and enter the system.
2. Insert the copied game data card into the TF2-GAME bit, after booting into the system, select(OPTIONS-ADVANCED-SWITCH TO SD2 FOR ROMS), and display the content of the game card after running.

Warning instructions

Without a system card, the device will only turn on yellow light without picture Display. At this time, you must insert the system card and press the reset key to enter the system.

If the software sets SD2 and pulls out TF2-GAME and turns on, it will also appear that the system does not wake.

Charging instructions

1. When the host red light flashes, please charge in time. After connecting DC to charge, the indicator shows static red.

1. If the red light starts flashing and does not charge in time, the host will be powered off automatically after about an hour of service. Please press the power key for 12 seconds until the green light is turned off and recharged. After about an hour, it will turn on normally. So please charge it in time.

Classical parameter

64bit
Four core Cortex-A7
1.5GHz CPU

5V 2A
Fast charging

Trigger structure
new feel

3.5 inches
640*480
HD screen

Dual TF card
Supports max 256 GB

10
Emulators

Configuration List

Video game handheld	*1
Type-c data line	*1
Certificate	*1
Product description	*1