

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at **kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

2.13M (7ft) SNOWY JASPER CHRISTMAS TREE – Tree L

Instruction Manual

includes:


- › Tree Top (section A)
- › Upper body (section B)
- › Lower body (section C)
- › metal stand



How to Assemble:

- 1) Before assembly check you have all contents, as per these instructions.
- 2) Place and assemble the tree on a level surface.
- 3) Insert section C of the tree into the metal stand, making sure that it's fully inserted and tighten and secure the screws.
- 4) Insert section B of tree into the top of section C.
- 5) Insert section A of tree into the top of section B.
- 6) Allow the branches to fall into place. Gently arrange tips up and out then shape the branches to your desired effect*

*Tip – For full effect of branches and tips, we suggest the following arrangement pattern. Starting with tips closes to the pole. One tip to the right, one tip to the left and one at the centre of the main stem. Repeat this pattern for each branch.



- 7) This product is for indoor use only.
- 8) Keep product away from the fire and other heat sources.
- 9) Please retain instructions for future reference.

Packaging Up and Storage Tips

- 1) Remove all lights and ornaments.
- 2) Remove sections as places, Section A and Section B.
- 3) Unscrew the tree stand from Section C before removing it from stand.
- 4) Each tree section, the branches should be pressed against the stem before placing inside carton.
- 5) Pack carton and store in a dry and damp free area.
- 6) Do not place product in direct sunlight or in an area where temperatures exceed 40 degrees.

Made in China