














SOUNDBAR WALL BRACKET


Please read and keep all safety and use instructions. • Læs og opbevar venligst alle sikkerheds- og brugsinstruktioner. • Bitte lesen Sie alle Sicherheitshinweise und Gebrauchsanleitungen durch und bewahren Sie sie auf. • Lees alle veiligheidsinstructies en de gebruiksaanwijzing door en bewaar deze. • Lea y conserve todas las instrucciones de uso y seguridad. • Lue ja säilytä kaikki turvallisuus- ja käyttöohjeet. • Lisez toutes les consignes de sécurité et les instructions d'utilisation. • Leggere e conservare tutte le istruzioni per la sicurezza e per l'uso. • Kérjük, olvassa el és tartsa be a biztonsági és használati utasításokat. • Les og ta vare på alle sikkerhets- og bruksinstruksjoner. • Należy zapoznać się ze wszystkimi zaleceniami dotyczącymi bezpieczeństwa oraz instrukcjami użytkowania i zachować je. • Leia e guarde todas as instruções de segurança importantes. • Läs igenom och spara alla anvisningar om säkerhet och användning. • โปรดอ่านและเก็บคำแนะนำด้านความปลอดภัยและการใช้งานทั้งหมดไว้ • 모든 안전 및 사용 지침을 읽고 보관하십시오. • 请阅读并保留所有安全和使用说明。 • 請閱讀並保管好所有安全和使用指示。 • 安全上の留意項目および使用方法をよく読み、それに従ってください。 • कृपया सभी सुरक्षा एवं इस्तेमाल के निर्देशों को पढ़ें व उनका पालन करें। • कृपया सभी सुरक्षा एवं इस्तेमाल के निर्देशों को पढ़ें व उनका पालन करें। • يُرجى قراءة كل التعليمات الخاصة بالسلامة والاستخدام والاحتفاظ بها.





- B (2)** 
- C (2)** 
- D (4)** 
- E (4)** 
- F** 
- G (2)** 




1



2




$\frac{3}{16}$ " (5 mm)
 $\frac{3}{32}$ " (2.4 mm)








Or
eller
Oder
Of
O
tai
Ou

Oppure
VAGY
Eller
lub
Ou
eller
หรือ


또는
或者
或
または
या
أو



3




④



Bose Soundbar 700 SoundTouch 300 Bose TV Speaker

5

Or Oppure 또는
eller VAGY 或者
Oder Eller 或
Of lub または
O Ou या
tai eller أو
Ou หรือ




Bose Soundbar 500

5


Or
eller
Oder
Of
O
tai
Ou

Oppure
VAGY
Eller
lub
Ou
eller
หรือ



또는
或者
或
または
या
أو




⑥



7





| | | | | | |
|---------------------------|--|--|--|-----------------------------|--|
| | | Wallboard Vægplade Gipskartonplatten Gipsplaat Yeso Levyseinä Plaque de plâtre Pannello in cartongesso Gipsz Karton Veggplate | Płyta ścienna Gesso Väggplatta แผ่นบอร์ดปิดผนัง 석고보드 墙板 牆板 板壁 दीवारबोर्ड لوح حائط | | |
| $\frac{3}{16}$ " (5mm) | | | | $\frac{1}{32}$ " (8.7mm) | |

| | | | | | |
|-----------------------------|--|--|---|--------------------------|--|
| | | Wood stud Træstolpe Holzständer Houten muurstijl Montante de mader Puukoolaus Montant en bois Montante in legno Fallécek Trestender | Ściana szkieletowa drewniana Esteio de madeira Träregel ผนังไม้ 나무 스테드 木墙筋 木立柱 木製間柱 लकड़ी का स्टड مسمار خشبي | | |
| $\frac{3}{32}$ " (2.4mm) | | | | $\frac{1}{8}$ " (3mm) | |

Not designed for masonry surfaces. • Ikke designet til at bruges på murværk. • Nicht für Mauerwerk geeignet. • Niet bestemd voor metselwerk. • No está diseñado para superficies de mampostería. • Ei tarkoitettu tiilipinnoille. • Non conçu pour les surfaces en maçonnerie. • Non progettato per superfici in muratura. • Nem alkalmas téglafalra szereléshez. • Ikke beregnet på muoverflater. • Produkt nie jest przeznaczony do powierzchni murowanych. • Não projetado para superfícies de alvenaria. • Inte till för användning på steniga ytor. • ไม่ได้ออกแบบสำหรับพื้นผิวที่เป็นอิฐ • 석조 표면에는 사용할 수 없음. • 非设计用于砌体表面. • 非設計用於砌體表面. • 本製品は、コンクリート壁用には設計されていません. • चिनाई सतहों के लिए नहीं बनाया गया है। • غير مصمم لأسطح البناء.

Please read and keep all safety and use instructions.

Important Safety Instructions



Contains small parts which may be a choking hazard.
Not suitable for children under age 3.

Do NOT make unauthorized alterations to this product.

The Bose Sound Bar Wall Bracket wall mounting kit is only for use with the Bose Soundbar 700, Bose Soundbar 500, Bose TV Speaker, and SoundTouch 300 soundbar.

Only use the mounting hardware supplied with this product.

Do not mount on surfaces that are not sturdy, or that have hazards concealed behind them, such as electrical wiring or plumbing. If you are not sure about installing the bracket, contact a qualified professional installer. Ensure the bracket is installed according to local building codes.

Only for mounting on the following surfaces:

- Wallboard $\geq 3/8$ " (10mm)
 - If mounted on surfaces other than stated above please contact a professional installer.

Due to ventilation requirements, Bose does not recommend placing the product in a confined space such as in a wall cavity or in an enclosed cabinet.

Do not place or install the bracket or product near any heat sources, such as fireplaces, radiators, heat registers or other apparatus (including amplifiers) that produce heat.

Warranty Information

This product is covered by a limited warranty from Bose.
For warranty details, visit global.bose.com/warranty

China Importer: Bose Electronics (Shanghai) Company Limited, Part C, Plant 9, No. 353 North Riying Road, China (Shanghai) Pilot Free Trade Zone

EU Importer: Bose Products B.V., Gorslaan 60, 1441 RG Purmerend, The Netherlands

Mexico Importer: Bose de México, S. de R.L. de C.V., Paseo de las Palmas 405-204, Lomas de Chapultepec, 11000 México.
Phone Number: +5255 (5202) 3545

Taiwan Importer: Bose Taiwan Branch, 9F-A1, No.10, Section 3, Minsheng East Road, Taipei City 104, Taiwan. Phone Number: +886-2-2514 7676

U.S. Phone Number: 1-877-230-5639

Bose, Bose Soundbar, Bose Soundbar Wall Bracket, Bose TV Speaker, SoundTouch, and the wireless note design are trademarks of Bose Corporation.
Bose Corporation Headquarters: 1-877-230-5639

© 2020 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.



BOSE SOUNDBAR 700:

worldwide.Bose.com/Support/SB700

BOSE SOUNDBAR 500:

worldwide.Bose.com/Support/SB500

SOUNDTOUCH 300:

global.Bose.com/Support/ST300

BOSE TV SPEAKER:


worldwide.Bose.com/Support/TVS



806657-0020

©2020 Bose Corporation
100 The Mountain Road
Framingham, MA 01701-9168 USA
AM806657-0020 Rev. 00

TV



H,I,J

Bose Soundbar 700
SoundTouch 300

Bose Soundbar 500
Bose Smart Soundbar 300

Bose Soundbar 500
Bose Smart Soundbar 300
Bose Soundbar 700
SoundTouch 300

Bose Soundbar 500
Bose Smart Soundbar 300





Bose Soundbar 700
SoundTouch 300

Bose Soundbar 500/Bose Smart Soundbar 300

Bose Soundbar 700/SoundTouch 300

9.37" | 238mm

15.91" | 404mm



A

TEMPLATE
 SKABELON
 SCHABLONE
 SJABLON
 PLANTILLA
 MALLI
 GABARIT
 DIMA
 SABLON
 MAL
 SZABLON
 GABARITO
 MALL
 模板
 留音尺
 範本
 テンプレート
 模板



