

Commercial Electric™

540 691



LAMP

3-WAY SOCKET
Turn Knob Style

Commercial Electric™

540 691
BRASS
LATÓN



Underwriters Knot
Nudo de seguridad



Tighten
Ajustar

Rated:
250W - 250V
Medium Base

Replace worn or broken sockets on a variety of light fixtures in your home. For use with #18 or Stranded Copper Wire Only.

WARNING:

- To avoid fire, shock, or death, unplug lamp or turn off power at circuit breaker or fuse and test that power is off before wiring.
- If you are not sure about any part of these instructions, consult a qualified electrician.
- Do not remove cardboard paper liner from shell or interior of cap.
- Do not install lamp holder if cardboard paper liner of shell or interior of cap is missing.
- Installation and/or use of a metal lamp holder without a cardboard paper liner in both shell and cap may cause electrical shock, personal injury, death, fire or property damage.

INSTRUCTIONS: Follow these instructions exactly to maintain the polarity of a correctly wire system.

1. Turn off power supply before installation.
2. To disassemble shell from cap press where indicated on shell. Remove wires from interior mechanism, and loosen set screw (if any) on bushing of old cap. Unscrew cap from pipe while holding pipe to prevent it from turning.
3. Pass wire through bushing on new cap. Screw cap onto pipe, tighten set screw on cap bushing securely. Insulating disk must be in bottom of cap.
4. Tie underwriters knot in wires (see diagram). Pull knot tight.
5. Strip insulation to expose 1/2 in to 5/8 in of bare copper strands. Be careful not to damage wire strands or insulation beyond stripped length.
6. Twist copper strands of each wire tightly together. Loop wires clockwise 3/4 turn around terminal screws. Firmly tighten screws over wire loops. Connect white or ribbed wire (or with color tracer or with silver strands) to silver terminal screw and remaining wire to brass terminal screw. Cut off any loose strands not secure under screw heads.
7. Slide metal shell (with insulating liner inside) over mechanism so switch is seated in slot(s) on shell and push shell firmly into cap until it locks securely and evenly into position. To assure locking, push on metal shell only.
8. Plug in lamp or restore power.

Lamp holder model ZE-309-3
MODEL/MODELO 81535



Recycle

MADE IN VIETNAM
DISTRIBUTED BY:
HOME DEPOT
2455 PACES FERRY RD., N.W.
ATLANTA, GA 30339
HOMEDEPOT.COM

MANUFACTURED AFTER 07/2018

