



SKU # 1007 581 535
Model # 22RT0272214

ASSEMBLY INSTRUCTIONS

3ft LED Marlin

USE AND CARE GUIDE

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on the ground. Many parts are connected by the lighting string that runs throughout the item. Take special care not to pull, cut or damage the lighting string. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. It is recommended to assemble parts of the product while laying flat on the ground or table versus standing the item up to assemble the parts. If any parts are missing or damaged do not attempt assembly but contact our customer service center or return to place of purchase with purchase receipt.

Assembly of this product may require more than one person.
1-855-HDHoliday (1-855-434-6543)

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 4.8 Watts (0.04 Amps). Do not overload. Do not connect to another lighting string, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Discard or return to place of purchase with purchase receipt if the product has cuts, damage, frayed wire insulation on cords, cracks in the socket enclosures, loose connections, exposed copper wire or other obvious damage.

Care and Cleaning

- Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product connections, and wires. If the product is placed somewhere other than the ground it should be well secured, flat and stable.
- Carefully disassemble the unit taking caution not to cut any electrical wires.
- Wipe the unit with a damp cloth and allow the unit to dry before storing.
- Store the product neatly in a cool, dry location protected from sunlight.

Troubleshooting

- Ensure that the floor or surface that the item sits on is flat and level
- Be sure to plug the item correctly to a wall outlet or a UL Listed Power Cord
- Ensure all parts are assembled properly per the Instruction Manual
- If the item does not light check for loose or broken bulbs and connections
- Do not plug into other electrical items
- If the item has multiple Light String Cords be sure to plug in all cords
- Check for Broken or Burned Out Fuse In Plug

Guarantee

What is Covered

The product is intended for residential seasonal use for 90 days maximum per year. This product is covered by a 90 days limited guarantee due to defects in material and workmanship. Return the product with purchase receipts to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse, in store display models or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday 1-855-HDHoliday (1-855-434-6543)



Thank you!


We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 3ft LED Marlin. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

1-855-HDHoliday (1-855-434-6543)
HOMEACCENTSHOLIDAY.COM

Parts List		
Locater	Name	Qty.
A	Bill / Mouth	1
B	Hat / Head	1
C	Body	1
D	Tail	1
E	Pectoral Fin	2
F	Dorsal Fin	2
G	Adipose Fin	2
H	Light String	1

Hardware List		
Locater	Name	Qty.
I	Spare Bulb	2
J	Spare Fuse	2
K	Plastic Tie	15
L	Ground Stake	4


Diagram of Parts



ASSEMBLY


1 Assembling the Tail and Adipose Fins

Insert the connecting rods on the top of Tail (D) into the connecting holes on the bottom of Body (C). Insert the connecting rods on the top of the Adipose Fins (G) into the matching holes on the Body (C) and fasten at connecting loops with Plastic Ties (K).




2 Assembling the Bill / Mouth and Head

The Bill / Mouth (A) comes with metal connecting bars on the top and bottom of the opened end. Insert the hooked end of the metal bars into the metal frame on the top of Head (B). Insert the connecting rods on the bottom of Mouth (A) onto the opening at the top of the Head (B). Insert the connecting rods on the bottom of Head (B) into the connecting holes on the top of Body (C) and fasten at the connecting loops with Plastic Ties (K).




3 Assembling the Pectoral Fins and Dorsal Fins

Insert the connecting rods on the Pectoral Fins (E) into the matching connecting holes on the Head (B) and Body (C). Insert the connecting rods on the front and rear Dorsal Fins (F) into the matching connecting holes of the Head (B) and Body (C).



4 Assembling the Light String

Wrap the Light String (H) around the Body of Billfish then secure the Light String with the Plastic Ties (K) at the metal frame locations specified in the diagram below.



5 Assembling the Ground Stakes

Insert Ground Stakes (L) over the metal frame on the Tail and the Adipose Fins per the diagram below then into the ground firmly.

