

HOME DECORATORS COLLECTION®


HANGTAG REMINDER



For More Troubleshooting
Information, Scan QR Code


Section Out?

Push & Rotate




Branch Lights Not Working ?

Push to unclip &
push back to secure




No Lights Working ?

Check for loose connection




Top Section Out?

Push & Rotate



Branch Hanging Low?

Bend up



Other Issue?



Call

1-800-986-3460