

PROAIM

Heavy-Duty 150mm Camera Tripod Stand with Spreader (P-CST-150)



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.




150mm Camera Tripod Stand



Aluminum Tripod Spreader


Aluminum Tripod Spreader Setup

- Remove the aluminum tripod spreader and place it on the floor.
- Open the legs to the required width and secure them using the provided knobs.



150mm Camera Tripod Stand

- Place the aluminum tripod stand onto the spreader and secure it with the provided knob.



- Lock the tripod stand in place using the rubber grips, as shown in the image.



- To adjust the height of the tripod, loosen all three adjustment knobs. Raise or lower the tripod to the desired height, then tighten the knobs securely.



- Your tripod stand with spreader is now fully assembled, as shown in the image.



- Mount the fluid head (**Not Included**) onto the Tripod Stand.



- Tighten the locking knob to secure it firmly in place.



- Press the red locking lever on the fluid head to unlock it.
- Once unlocked, release the yellow locking lever and remove the fluid head top plate.



- Attach the top plate to the camera (**Not Included**) by aligning the threads properly.
- Secure the top plate to the camera using a screwdriver.



- Mount the camera onto the fluid head and lock it securely in place, as shown in the image.
- The setup is now ready for use.



**YOUR PROAIM HEAVY-DUTY 150MM CAMERA TRIPOD STAND WITH SPREADER
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty for our products from the date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs, nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subject to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please contact us immediately, and we promise our utmost support and care until you use our product.