




Number	Name
B1	Engin
B2	Buffer Spring Buckle
B3	Knob Buffer Spring
B4	Knob
B5	Rope
B6	Cover
B7	Bolt St5x18
B8	Bolt St5x16
B9	Spring
B10	Spring Kit
B11	Reel
B12	Start Spring
B13	Reel
B14	5x14x1.2 Gasket
B15	St5x16 Bolt
B16	Cover
B17	Dustproof Cover
B18	Right Damper
B19	Left Damper
B20	Dustproof Cover
B21	Handle Spring Plate
B22	Handle Spring
B23	Air Filter Washer
B24	Air Filter
B25	Handle
B26	Top Cover
B27	Air Filter Cover
B28	Nut Rubber Gasket
B29	Air Filter Nut
B30	Air Filter Anti-Vibration
B31	Plate
B32	Throttle Anti-Vibration
B33	Choke
B34	St4x8 Bolt

Number	Name
B35	Plate
B36	St4x10 Bolt
B37	Brake Spring Plat
B38	Brake Spring
B39	Band
B40	Adjusting Screw Gear
B41	Adjusting Screw
B42	Brake Plate
B43	Ms Nut
B44	Punck Socket
B45	Guard Socket
B46	M5x40 Bolt
B47	Punch
B48	Punch Spring
B49	Adjusting Screw Pin
B50	Front Baffle Buffer Spring
B51	Buffer Spring Brankt
B52	Main Lever
B53	Vice-Lever
B54	Brake Lever
B55	Pin 3x19
B56	Pin 3x14
B57	M5 Nut
B58	Washer Guard
B59	Brake Spring
B60	Guard
B61	Oil Cap
B62	Gasket Oil Cap
B63	Oil Pat
B64	Switch
B65	Bolt
B66	Fuel Tank
B67	Oil Bubble

Number	Name
B68	Oil Filter Spring
B69	Rubber Handle Cover
B70	Trigger Contra
B71	Trigger
B72	Trigger Torsion Spring
B73	Pin 5x25
B74	Balancer
B75	Oil Pipe
B76	Fuel Pipe
B77	Fuel Filter
B78	Balancer
B79	Base Tension Spring
B80	M5x12 Bolt
B81	Oil Pat
B82	Gasket Fuel Tank 1
B83	Cover
B84	Bar Cover
B85	Bar
B86	Chain