



HDMI 2.0 Switch 2ways 2-1 4K60


Quick guide

509-22



www.sandberg.world

Product overview



1. HDMI-1, input in switch-mode
HDMI-1, output in splitter-mode
2. HDMI-2, input in switch-mode
HDMI-2, output in splitter-mode
3. HDMI-input when used as splitter
HDMI-output when used as switch

4. Switch button:




Up position:
HDMI-1 selected



Down position:
HDMI-2 selected

Splitter-mode



Switch-mode





Support

<http://helpdesk.sandberg.world>

Warranty

There is a five-year warranty on your Sandberg product.
Please read the warranty terms and register your new
Sandberg product at www.sandberg.world/warranty

5
Years
Warranty



For information on handling electronic waste, see www.sandberg.world/weee