

Product Instruction Manual

1. Product Information

Product Name: Parking Heater

2. MANUFACTURER & EU REPRESENTATIVE INFO

Manufacturer: [Guangzhou Kuxiong Shi Trading Co., Ltd

No. 503, Building 3, Courtyard 2, Zhongquantang Road, Industrial Avenue, Haizhu District,
Guangzhou City

86-18814180059

tingting26181@outlook.com]

EU Authorized Representative: [Sea&Mew Consulting GmbH

Mittenhuber Stra?e 4, 92318 Neumarkt

+4915224685061

Compliance.EU@outlook.com]

3. Compliance Information



4. Safety & Warnings

⚠ **Warning:** Keep flammable materials away from the heater. Do not operate in a closed space without ventilation. Avoid touching the heater during operation to prevent burns. Keep children and pets away. Follow maintenance schedules strictly.

5. Instructions for Use

- 1.Preparation: Ensure the vehicle is parked on a level surface and the engine is off.
- 2.Turn on heater: Activate the parking heater according to the control panel or remote instructions.
- 3.Adjust settings: Set the desired temperature and duration.
- 4.Monitor operation: Ensure ventilation is unobstructed and no unusual noises occur.

5. Turn off heater: Switch off the heater after use and allow it to cool before touching.

After use: Check that the heater and surrounding area have cooled completely.