

**VENTION®**

## **20000mAh Power Bank**

User Manual | VWS-H35

## Notes

1. Fully charge the power bank before first use to ensure optimal performance.
2. Perform a full charge cycle (0% to 100%) every 2-3 months for accurate battery level readings.
3. Avoid overcharging—disconnect the power bank once fully charged. Do not drain the battery completely; recharge when the level drops over 20% to prolong battery life.
4. For long-term storage, maintain a charge level between 40-80% to prevent over-discharge and battery degradation.
5. Do not store the power bank above 45°C or in direct sunlight. Do not put it in fire or any other hot environments.
6. Do not disassemble, repair, modify, or replace any parts of the power bank.
7. Do not drive nails into the power bank or hit it with a hammer.
8. Do not immerse the power bank in water or expose it to moisture.
9. The power bank may warm up during use, but if it stays below 45°C, it's safe to use.
10. Carry the power bank in a shockproof, moisture-proof bag and keep it away from metal objects like keys or coins to prevent short circuits.
11. If the power bank becomes unusually hot, swells, or emits a smell, stop using it immediately and keep it away from fire.
12. Use good-quality charging cables; damaged cables can lower charging efficiency and pose safety risks.

## **Instructions for Use**

1. The built-in USB-C cable allows both charging other devices and recharging the power bank itself.
2. Connect the built-in USB-C cable to a laptop, tablet, or phone. You can also connect additional cables to charge up to three devices simultaneously.
3. Use a USB-C charger with the built-in cable, plug it into a power outlet, and recharge the power bank. Alternatively, use another compatible USB-C charging kit.
4. Disconnect the power bank once charging is complete.

## **Maintenance and Cleaning**


Gently clean the power bank with a dry, soft cloth to avoid internal short circuits. Do not use corrosive cleaners as well.

## **Warranty and After-Sales Service**

This product comes with a 1-year warranty. If there is non-human damage during normal use, please contact our customer service, and we will provide you with service and support.

The warranty does not cover damages caused by human factors, improper use, or failure to operate in accordance with the instructions provided.


## Packaging List



20000mAh Power Bank x 1



Drawstring bag x 1



User Manual x 1

For more interesting information and events, please follow us on social media platforms:



Facebook




LinkedIn



Instagram

For warranty service or support, please contact Vention team:  
Website: [www.ventiontech.com](http://www.ventiontech.com) Email: [vention@ventiontech.com](mailto:vention@ventiontech.com)


# Product Overview



③ USB-A


② USB-C

① Built-in USB-C Cable



④ TFT Digital Display

Power Button ⑤



⑥ 100W USB-C Cabl

## Introduction

Dear customer, thanks for your trust in Vention. This manual is designed to provide you with all the information you need. Please read this manual carefully before use and keep it properly for future reference.

## Specifications

**Model:** FKC

**Material:** PC + ABS

**Interface:** USB-A/USB-C

**Battery Capacity:** 5000mAh (14.8V/74Wh)(5000\*4)

**Input (USB-C):** 5V $\Rightarrow$ 3A; 9V $\Rightarrow$ 3A; 12V $\Rightarrow$ 3A; 15V $\Rightarrow$ 3A; 20V $\Rightarrow$ 3.25A (65W Max)

**Output (USB-A):** 5V $\Rightarrow$ 3A; 9V $\Rightarrow$ 2A; 12V $\Rightarrow$ 1.5A; 10V $\Rightarrow$ 2.25A (22.5W Max)

**Output (USB-C):** 5V $\Rightarrow$ 3A; 9V $\Rightarrow$ 3A; 12V $\Rightarrow$ 3A; 15V $\Rightarrow$ 3A; 20V $\Rightarrow$ 5A (100W Max)

**Output (USB-A + USB-C):** 5V $\Rightarrow$ 3A (15W Max)