

VEVOR

Affordable. Reliable. Home Improvement.

**AUTOMOTIVE TAIL
LIGHT ASSEMBLIES**

MODEL: 15YKL

VEVOR

Affordable. Reliable. Home Improvement.

AUTOMOTIVE TAIL LIGHT ASSEMBLIES

MODEL: 15YKL



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

IMPORTANT SAFEGUARDS



WARNING: Read and understand this entire manual before operating or servicing this product. Failure to follow these warnings and instructions can cause personal injury or damage to valuable property.

- Avoid children using the product. And this product is not a toy. Do not allow children to play.
- It is highly recommended that you go to a professional car modification service shop for replacement installation.

ASSEMBLY PRECAUTIONS

1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly and use.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble when tired or when under the influence of alcohol, drugs or medication.
6. Product capabilities apply to properly and completely assembled products only.
7. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area. Please keep small spare parts out of children's reach.

SAVE THESE INSTRUCTIONS

PROBLEM POINTS AND SOLUTIONS

COMMON CAUSES OF TAILLIGHT CONDENSATION	Solution
Large changes in daily temperature	Check that all vents are free from blockages. Turn on the lights for 20mins to raise the taillight temperature and evaporate condensation.
Leaking seals on bulbs and/or bulb sockets	Remove bulbs to allow moisture to evaporate from inside the housing.Heat with a hairdryer to speed up the process.
Taillight turned on and the bulbs heated up inside the housing the hot air will turn into moisture.	Leaking seals on bulb sockets. Put moisture absorbing silica-gel desiccant packet inside the taillight.

SPECIFICATION

Model	15YKL
Material	ABS+PC+PMMA
Rating for light	DC12V
Position	LH
Color	Red
Light source	LED and Halogen lamp
Suitable vehicle	GMC Yukon 2015-2020

PACKAGE LIST

①Tail Light Assemblies*1, ② Manual *1,③Bracket*1

Replacement

※ Please check the maintenance manual of the vehicle;

HINT:

The Install procedure for the RH side is the same as that for the LH side.

STEP1: Remove existing tail light

1.Remove this little retainer clip right. If you don't have one of these, you can probably use a claw hammer or something.



2.Remove this whole panel right here.



3.Remove 2 screws out it pretty much is just gonna slide off.



4. Remove the original factory taillight assembly and the tail light sockets. Underneath the vehicle near the back bumper, we're going to disconnect the connector right here. There is a little lock tab. You can use a pick or screwdriver just push back on that lock tab and then you should be able to slide the connector right off.



STEP2: Install the new taillight.

1. Connect taillight harness, slide it down the way the old one came out, and then there's a tab on the bottom you want to line that up with the bottom down there and the two pins on the side line those up get those all lined up just push it in make sure it's all the way down.



2. Take the two screws line the screws up and tighten those down foreign.



3. Take this cover line it up and lock it in place, and then insert this little retainer clip.



4. Line the connector up once it's clipped in push down on the lock. then test the lights.



Complete the replacement.



Sanven Technology Ltd.

**Address: Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA
91730**

