

Halo
GEL POLISH PLUS
THE NEW PREMIUM
RANGE OF HALO
GEL POLISH

STEP BY STEP
FOR THE **PERFECT** SET



pureNAILS

pureNAILS

A STEP BY STEP GUIDE TO

Halo
GEL POLISH PLUS

APPLICATION

- 01** Prep the nails by shaping, carrying out cuticle work and removing any surface shine using a **Halo Elite Buffer**.
- 02** Remove any dust and surface oils by cleaning the nail plate using **Halo Prep & Scrub**.
- 03** Apply a thin layer of your chosen **HGP+ Base Coat**, sealing the free edge.
- 04** Cure for 60 seconds in your Halo Lamp.
TOP TIP We recommend a Halo Lamp to get the optimum cure that we test!
- 05** Before applying your **HGP+** colour of choice, scrape off any excess gel on the neck of the bottle. This formula will need thin coats!
- 06** Apply a thin layer of your chosen HGP+ shade to the nail, remembering to seal the free edge. Cure for 60 seconds.
- 07** Repeat steps 5 & 6 for your second coat of HGP+ colour. Seal the free edge and cure for 60 seconds.
- 08** Apply your chosen **HGP+ Top Coat**, seal the free edge and cure for 60 seconds.
- 09** If using a top coat which needs wiping, wait 5 seconds for the nails to cool and remove the sticky layer with a **Halo Elite Nail Wipe**.
- 10** Allow nails to cool for 2 minutes before applying our **Halo Citrus Crush Cuticle Oil**.



For more information on Halo products, get in touch: nailtechsupport@purenails.co.uk



REMOVAL

- 01** Heat the Halo Heat Mitts for 120 seconds in the microwave, before filing and buffing the nail with our Halo Precision File.

- 02** Apply Acetone to your Halo Foil Wraps and wrap each nail tightly.
TOP TIP Simply just buff and use foils or a soak off bowl if you do not have our mitts!
- 03** Place hands into the Heat Mitt Liners and cover with the Halo Heat Mitts.

- 04** Leave for 7 minutes before removing one hand at a time and checking with your Halo Gel Scraper. Repeat steps if required.
- 05** Once all product is removed, gently file and buff the nail and finish with cuticle oil or proceed to prep for another application.


