



User Manual

FERREX®

709610

20V LI-ION CORDLESS BLOWER SKIN



Product
Info



<https://help.tools/>

Read all safety warnings and all instructions thoroughly before operating this product.

Ensure you keep your manual in a safe place for future reference.

IM ed 2; 10/2022

QR codes take you where you want to go quickly and easily

Whether you require product information, spare parts or accessories, details on warranties or after sales service, or if you want to watch a product demonstration video, our QR codes will take you there in no time at all.

What is a QR code?

A QR-code (QR=Quick Response) is a type of matrix that can be read with a smartphone camera and that contains a link to a website or contact details, for example.

Advantage: You are not required to manually enter a website address or contact details.

How it works

To scan the QR code, all you need is a smartphone with QR codes reader software and an Internet connection*. This type of software can be downloaded for free from your smartphone's app store.

Try it out now

Just scan the QR code with your smartphone and find out more about the Aldi product you have purchased*.



* Depending on your tariff you may be charged for the connection.



FERREX®



20V Li-Ion Cordless Blower Skin Warranty details

REGISTER YOUR PURCHASE AT www.aldi.com.au/en/about-aldi/product-registration/ TO KEEP UP-TO-DATE WITH IMPORTANT PRODUCT INFORMATION.

The product is guaranteed to be free from defects in workmanship and parts for a period of 60 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AFTER SALES SUPPORT

  1800 909 909
(toll free)

e-mail: info.aldi@positecgroup.com
MODEL No.: CBV18F.9 • 10/2022 • 709610



Contents

Pack contents / parts	2
Description of symbols	3
General Safety Warnings	5
Additional safety warnings for cordless Blower	8
Parts List	10
Assembly	11
Unpacking	11
Removing or installing the battery pack	11
Operation	12
Starting & stopping	12
Using the blower	12
Adjusting the blowing speed	13
Residual risk	13
Maintenance	14
Clean and Storage	14
Cleaning the blower	14
Storage	14
Warranty	15
Environmental Protection	15
What your 3 year warranty means	16
Service Support	16
Accessories and After Sales Parts	16
Troubleshooting	17
Technical Specifications	17

Pack contents / parts

Congratulations on the purchase of your FERREX® 20V Li-Ion Cordless Blower Skin. When you open your packaging, first remove all items and check there are no parts damaged or missing. If you find anything wrong, do not operate the product until the parts have been replaced or the fault has been rectified. Failure to do so could result in serious personal injury.

Application

First time users or inexperienced operators pay particular attention to the operation of the 20V Li-Ion Cordless Blower Skin, including details of starting and stopping and correct use of the 20V Li-Ion Cordless Blower Skin on pages 12-13, as well as the maintenance instructions on page 14.

Intended use of the 20V Li-Ion Cordless Blower Skin

It is exclusively intended for home use. It is not designed for trade or commercial use.

This 20V Li-Ion Cordless Blower Skin is intended for residential use only. Use the blower outdoors to move yard leaves and debris as needed.

Any other use or change to the appliance is deemed improper and poses a significant risk of accidents.

Contents of carton

- 1 x 20V Blower (skin)
- 1 x Blow tube
- 1 x Instruction Manual
- 1 x Warranty Card & details

Description of symbols

The instruction manual, rating plate, or on the product itself, may show these symbols. These represent important information about the product or instructions on its use.



To reduce the risk of injury, user must read instruction manual



Keep bystanders away.



Warning of hazard



Do not use in the rain or leave outdoors while it is raining.



Wear hearing protection.
Wear eye protection.
Wear breathing protection.



Wear eye protection.



To reduce the risk of injury, user must read instruction manual



Conforms to relevant standards for electrical safety and electromagnetic compatibility.



Warning



60 Months Warranty



The box is recyclable at the kerbside.



The inserts are recyclable at the kerbside.

General safety warnings



WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term “power tool” in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1) Work area safety

- a) **Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- b) **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- c) **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2) Electrical safety

- a) **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- c) **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- d) **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.

- e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** *Use of a cord suitable for outdoor use reduces the risk of electric shock.*
- f) **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** *Use of an RCD reduces the risk of electric shock.*

3) Personal safety

- a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** *A moment of inattention while operating power tools may result in serious personal injury.*
- b) **Use personal protective equipment. Always wear eye protection.** *Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.*
- c) **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** *Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.*
- d) **Remove any adjusting key or wrench before turning the power tool on.** *A wrench or a key left attached to a rotating part of the power tool may result in personal injury.*
- e) **Do not overreach. Keep proper footing and balance at all times.** *This enables better control of the power tool in unexpected situations.*
- f) **Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** *Loose clothes, jewellery or long hair can be caught in moving parts.*
- g) **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** *Use of these devices can reduce dust-related hazards.*

4) Power tool use and care

- a) **Do not force the power tool. Use the correct power tool for your application.** *The correct power tool will do the job better and safer at the rate for which it was designed.*

- b) Do not use the power tool if the switch does not turn it on and off.**
Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.** *Such preventive safety measures reduce the risk of starting the power tool accidentally.*
- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** *Power tools are dangerous in the hands of untrained users.*
- e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** *Many accidents are caused by poorly maintained power tools.*
- f) Keep cutting tools sharp and clean.** *Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.*
- g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** *Use of the power tool for operations different from those intended could result in a hazardous situation.*

5) Battery tool use and care

- a) Recharge only with the charger specified by the manufacturer.** *A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.*
- b) Use power tools only with specifically designated battery packs.** *Use of any other battery packs may create a risk of injury and fire.*
- c) When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** *Shorting the battery terminals together may cause burns or a fire.*
- d) Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.** *Liquid ejected from the battery may cause irritation or burns.*

6) Service

- a) **Have your power tool serviced by a qualified repair person using only identical replacement parts.** *This will ensure that the safety of the power tool is maintained.*

Additional safety warnings for cordless Blower

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

The appliance is designed only for blowing of dry leaves in private households and as a hobby appliance in the garden. Any other utilization, which is not explicitly approved in these directions, can lead to damage to the appliance and represent a serious danger to the user.

- The appliance is designed for use by adults. Young people over 16 years may use the appliance under supervision only.
- The use of the appliance in the rain or in a humid environment is forbidden.
- The manufacturer is not liable for damage which is caused through inappropriate use or incorrect operation.

NOTE: Do not employ and low power machines for heavy work. **DO NOT** use your device for purposes for which it has not been designed.



WARNING! To reduce the risk of injury, user must read and understand instruction manual.

1) Training

- a) Read the instructions carefully. Be familiar with the controls and the proper use of the appliance.
- b) Never allow children to use the appliance.
- c) Never allow people unfamiliar with these instructions to use the appliance. Local regulations may restrict the age of the operator.
- d) Never operate the appliance while people, especially children, or pets are nearby.
- e) The operator or user is responsible for accidents or hazards occurring to other people or their property.

2) Preparation

- a) While operating the appliance, always wear substantial footwear and long trousers. Do not operate the equipment when barefoot or wearing open sandals.
- b) Do not wear loose clothing or jewellery that can be drawn into the air inlet. Keep long hair away from the air inlets.
- c) Wear protective goggles while operating.
- d) To prevent dust irritation the wearing of a face mask is recommended.
- e) Never operate the appliance with defective guards or shields, or without safety devices.

3) Operation


- a) Take off the battery from the appliance,
 - when not in use;
 - before clearing a blockage;
 - before checking, cleaning or working on the appliance;
 - if the appliance starts to vibrate abnormally.
- b) Operate the appliance only in daylight or in good artificial light.
- c) Do not overreach and keep your balance at all times.
- d) Always be sure of your footing on slopes.
- e) Walk, never run;
- f) Keep all cooling air inlets clear of debris.
- g) Never blow debris in the direction of bystanders.
- h) Do not put hands or feet near or under rotating parts.

4) Maintenance and storage

- a) Keep all nuts, bolts and screws tight to be sure the appliance is in safe working condition;
- b) Replace worn or damaged parts.
- c) Use only genuine replacement parts and accessories.
- d) Store the appliance only in a dry place.

Parts List

1. On/off switch with variable speed control
2. Handle
3. Battery pack compartment
4. Motor housing
5. Blow tube
6. Tube release button
7. Battery pack release button*
8. Battery pack*



* Battery is not included with this product

Assembly

WARNING: Before assembling and disassembling the blower tube, be sure the on/off switch is in "0" Off position and remove the battery pack from the blower.

1. Unpacking (See Fig. A)

Unpack all parts and lay them on a flat, stable surface. You will find a blower tube (5) is provided with main machine. The blower tube (5) needs to be fitted to the blower housing before proceeding to use.

2. Assembling and disassembling the blower tube (See Fig. B1, B2)

To assemble, press the tube release button (6) and slide the blower tube (5) into the motor housing (4). Ensure the tube release button (6) on the blower tube (5) aligns with the arrow (a) on the motor housing (4).

To disassemble, press the tube release button (6), and remove the blower tube (5) from the motor housing (4).




NOTE: Do not try to separate the tubes by force or by using tools.

3. Removing or installing the battery pack *

WARNING: Before inserting the battery pack, make sure that the on/off switch (1) is in OFF position.

Depress the battery pack release button (7) to release and slide the battery pack (8) out from the battery pack compartment (3). After recharging the battery, slide the battery pack back into battery pack compartment (3). A simple push and slight pressure will be sufficient. (See Fig. C)

* Battery is not included with this product




Operation

1. Starting & stopping (See Fig. D)

- Starting

Move the on/off switch (1) to the "1", "2", "3", "4" or "MAX" to start the blower. Speed "1" is the lower speed. Speed "MAX" is the highest speed.



- Stopping

Move the on/off switch (1) to the "0" Off position.



WARNING! The blower runs for a few seconds after it has been switched off.

NOTE: Let the motor come to a complete standstill before setting the blower down.

2. Using the blower



WARNING: During operation of the blower it is recommended to wear eye protection, a dust mask, and full hearing protection. Ensure you are wearing suitable clothing.

User tips

- Adjust the blowing speed according to the desired working condition.
- Hold the blow tube approximately 20 cm above the ground when operating the blower.
- Use a sweeping motion from side to side. Advance slowly keeping the accumulated debris/leaves in front of you.
- After blowing the debris/leaves into a pile, it is easy to dispose of the pile.



Caution!

- Do not blow hard objects such as nails, bolts, or rocks. It is recommended to inspect the area you are blowing before starting use



to ensure this does not occur.

- Do not operate the blower near bystanders or pets.
- Use extra care when cleaning debris from stairs or other tight areas.
- Wear safety goggles or other suitable eye protection, long pants, and shoes.

3. Adjusting the blowing speed (See Fig. E1, E2)

Move the on/off switch (1) to "1" position, and the blower will run at a lower speed. (See Fig. E1)

Move the on/off switch (1) to "MAX" position, and the blower will run at the highest speed. (See Fig. E2)



Residual risk

Even if you use the 20V Li-Ion Cordless Blower properly per the instructions provided and following all safety notes, there are always residual risks. The following risk may occur:

- Accidental Starting: Always remove the battery pack from the blower before carrying out any adjustment, servicing or maintenance. When not in use, store the blower in a safe, dry, clean environment.
- Risk of blowing: Do not direct the output of the blower tube at any person, the operator, or any animals. Never place hands in front of nozzle, direct blowing away from self or others, and always operate in an area clear of all persons, pets and obstacles. Do not operate the product when fatigued or under the influence of alcohol or drugs, stay alert at all times.

Reduce residual risks by using the 20V Li-Ion Cordless Blower with care and following all safety notes as well as other instructions.

Maintenance

Remove the battery pack from the tool before carrying out any adjustment, servicing or maintenance.

There are no user serviceable parts in your blower. Never use water or chemical cleaners to clean your blower. Wipe clean with a dry cloth. Keep the motor ventilation slots clean. Keep all working controls free of dust.

Cleaning and Storage

1. Cleaning the blower

Clean the blower regularly after each use.



Warning!

- **Keep your blower dry. Under no circumstances spray with water.**
- **To clean the blower, use only mild soap and a damp cloth.**
- **Do not use any type of detergent, cleaner or solvent which may contain chemicals that could seriously damage the plastic.**
- **Self lubricating bearings are used in your product, therefore lubrication is not required.**

2. Storage

- Dry all parts thoroughly before using the device again or store it. Always keep the openings clean and dry.
- Store the blower indoors, in a cool dry location, that is protected from dust, moisture and direct sunlight and that is also out of the reach of children and animals.

Warranty

Your new FERREX® 20V Li-Ion Cordless Blower Skin will more than satisfy your expectations.

It has been manufactured under stringent FERREX® Quality Standards to meet superior performance criteria.

You will find your new 20V Li-Ion Cordless Blower Skin easy and safe to operate, and, with proper care, it will give you many years of dependable service.

CAUTION. Carefully read through this entire instruction manual before using your new FERREX® 20V Li-Ion Cordless Blower Skin.

Take special care to heed the Cautions and Warnings.

Your FERREX® 20V Li-Ion Cordless Blower Skin has many features that will make your job faster and easier. Safety, performance, and dependability have been given top priority in the development of this 20V Li-Ion Cordless Blower Skin, making it easy to maintain and operate.

Use only FERREX® replacement parts for your product.

Non-conforming parts or modifications made to parts will void your warranty.

Environmental protection



Recycle unwanted materials instead of disposing of them as waste. All tools, hoses and packaging should be sorted, taken to the local recycling centre and disposed of in an environmentally safe way. Dispose of used motor oil in a manner that is compatible with the environment. We suggest you take it in a sealed container to your local service station for reclamation. Do not throw it in the trash or pour it into the earth.

Disposing of the packaging

Please make sure that the packaging is disposed of in an environmentally friendly way.

Disposing of the product

If the product should no longer work at all, please make sure that it is disposed of in an environmentally friendly way and according to local regulations.

What your 5 year warranty means?

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first 5 years after the date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product please contact us via our after sales support services, details of which can be found in this manual and on the product itself.

After Sales Support TEL: 1800 909 909

Service Support

If you have any issues with the operation of your product, please call us 1800 909 909 for advice, or email us at info.aldi@positecgroup.com.

Accessories and After Sales Parts

Accessories and after sales parts are available for purchase by visiting <https://help.tools/> or calling our customer service hotline on: 1800 909 909



1. CBV18F.9-BT:
Replacement Blower
Tube

Troubleshooting

Symptom	Possible causes	Solution
Product does not start	1.1 Battery pack is not installed correctly. 1.2 Battery capacity is low. 1.3 Battery pack is too hot/cold.	1.1 Install the battery pack per the instructions provided. 1.2 Charge the battery pack. 1.3 Allow to cool/warm.

For further inquiries or issues associated with your 20V Cordless Blower Skin, call our Customer Service on 1800 909 909 or email us at info.aldi@positecgroup.com

Technical Specifications

Rated voltage	20 V d.c.
No-load speed	17000RPM
Blower speed	138km/h
Air volume	590m ³ /h
Product dimensions	820*280*170 mm
Machine weight	1.96 kg

This 20V Li-Ion Cordless Blower Skin is compatible only with the ALDI range of 20V Xfinity Plus Batteries and Chargers, which can be purchased at your local ALDI store.

This 20 V Li-ion Cordless Blower complies with the following standards:

Safety:	AS/NZS 60335.1 AS/NZS 60335.2.100
EMC:	CISPR 14-1

This is a blank page

This is a blank page

This is a blank page



ALDI guarantees that our exclusive brand products are developed to our stringent quality specifications. If you are not entirely satisfied with this product, please return it to your nearest ALDI store, within 60 days from the date of purchase, for a full refund or replacement, or take advantage of our after sales support by calling the supplier's Customer Service Hotline.



Made in China

FERREX® is a registered trademark of ALDI Stores

DISTRIBUTED BY:

ALDI STORES

1 SARGENTS ROAD

MINCHINBURY NSW 2770

www.aldi.com.au

AFTER SALES SUPPORT



1800 909 909 (toll free)

e-mail: info.aldi@positecgroup.com

MODEL: No. CBV18F.9 • 10/2022 • 709610

5

YEAR WARRANTY