



120W Soundbar

MT120-5-SB21

Index

Content	Page
1. Inclusions	1
2. Matters Need Attention	2
3. Technical Specifications and Features	2
4. Accessories	3
5. Connections	3
6. LED Display	4
7. Remote Control	4
8. Control Panel Keys	5
9. Input Functions	6
10. Trouble Shooting	8

USER MANUAL

Thank you for purchasing this Soundbar, please read this instruction manual carefully before using this product to ensure proper use. Keep this manual in a safe place for future reference.

A compact yet powerful Bluetooth soundbar with sleek looks and excellent audio response. 4 speakers, 1 subwoofer and 2 bass air tubes provide clarity across a broad frequency range, with crisp highs and deep bass. USB port enables playback of MP3/WAV files directly from compatible media, with further flexible input options including AUX, HDMI(ARC), Optical and Bluetooth. A convenient and cost-effective TV audio upgrade that doesn't compromise on performance.

Inclusions



Slender and stylish metallic grey design



4 speakers for crisp, clear sound with deep bass




Inbuilt 2.0 channel amplifier with 3 EQ presets



Versatile input options to support a range of devices



USB port for MP3 and WAV media playback



Remote control and AUX cable included

Attention Required

- Please place the product in a cool and dry place to avoid hazardous failures
- To reduce the risk of electronic shock or fire, do not remove the cabinet cover. Please contact a service professional.
- In the rare occurrence of a malfunction, do not attempt to repair the unit on your own. Contact a certified service technician for a proper diagnosis and repair.
- If fragments or liquids fall into the device box, please cut off the power right away. It can be used only after a service technician checks it.
- Don't install the unit in or near a place where it may come in contact with rain, moisture or other liquids.


Technical Specifications and Features

- **Peak Power:** 120W
- **Speaker drivers:** 2.25" speakers x 4 + 6.5" subwoofer x1v
- **Frequency:** 50Hz-18KHz
- **SNR:** >70dB
- **Bluetooth version:** 5.0+EDR
- **Bluetooth range:** Up to 10m
- **Connections:** USB 2.0, AUX (3.5mm), Optical input, HDMI ARC, Wired subwoofer
- **Power supply:** 110V-240V
- **Dimensions:** Soundbar: 900 x 95 x 65 mm, Subwoofer: 220 x 150 x 340mm

Accessories

- User manual **x 1**
- Remote control **x 1**
- Power cord **x 1**
- AUX-in cable **x 1**
- Wall-mounting kits **x 1**

Connections




- 1 HDMI(ARC):** Use to connect compatible devices using a HDMI cable (not provided with the product).
- 2 OPTICAL IN:** Use to connect compatible devices using an optical cable (not provided with the product).
- 3 AUX IN:** Use to connect compatible devices using the 3.5mm – 3.5mm stereo jack cable (provided with the product).
- 4 USB IN:** Use to connect a flash drive for direct MP3/WAV playback (FAT32 format and 64GB max).
- 5 AC IN:** Use to connect the AC power supply (power cord pr

LED display


1. **Red LED:** Standby mode
2. **BT:** Bluetooth mode
3. **USB:** USB media mode
4. **AUX:** Auxiliary input
5. **OPT:** Optical mode
6. **ARC:** HDMI (ARC) mode

Remote Control



Button	Function	Button	Function
	Power on/off	MODE	Shifting to BT/USB/AUX/OPT/HDMI(ARC)
	Mute or recover the volume	BT	Shifting into BT mode In BT mode, hold to enter pairing mode
TREBLE+	Increase the Treble	USB	Shifting into USB Mode
TREBLE-	Decrease the Treble	AUX	Shifting into AUX Mode
VOL+	Turn up volume	HDMI ARC	Shifting into HDMI (ARC)Mode
VOL-	Turn down volume	OPT	Shifting into Optical in Mode
	Previous track	EQ	Shifting to different EQ
	Pause/Play		USB repeat mode
	Next track	3D	3D surround sound on/off
BASS+	Increase the Bass	BASS-	Decrease the Bass

Control Panel Keys



- 1** Pause/Play
- 2** Turn up volume/ Next Track
- 3** Turn down volume/ Previous track
- 4** Power on/off

Input Functions

- **Power on/off:** Press the power on/off button on the remote control or soundbar control panel to turn the unit on and off.
- **HDMI(ARC):** Connect an HDMI ARC compatible device to the HDMI(ARC) port on the soundbar using a HDMI cable (not supplied). Select HDMI(ARC) mode either by pressing the HDMI(ARC) button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until ARC is displayed on the LED display. Ensure HDMI ARC is selected as the TV's audio output, then adjust the volume of soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- **AUX in:** Connect a compatible device using the 3.5mm – 3.5mm stereo jack cable. Select AUX mode either by pressing the AUX button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until AUX is displayed on the LED display. Ensure the connected device is producing an audio signal, then adjust the volume of soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- **Optical in:** Connect a compatible device to the OPTICAL input on the soundbar using a digital optical cable (not provided with the product). Select OPT mode either by pressing the OPT button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until OPT is displayed on the LED display. Ensure Optical SPDIF is selected as the TV's audio output, then adjust the volume of the soundbar using the Volume Up and Volume Down buttons on the remote control or soundbar control panel.
- **Bluetooth:** Press the BT button on the remote control or repeatedly pressing the MODE button on the soundbar control panel until bt is shown on the LED display. The LED display will flash to indicate that the soundbar is in Bluetooth pairing mode. Ensure that the device you wish to connect is also in pairing mode and search for "MT120-5-SB21" in its device list. When the two devices are paired, the LED display on the soundbar will stop flashing and remain constant. (The soundbar will now automatically re-pair with this device whenever it is within range and has Bluetooth turned on.)

- **USB media mode:** The soundbar is compatible with USB flash drives of up to 64GB(FAT32 format) in size and can play MP3 and WAV audio files directly. Simply insert a compatible drive into the USB port on the back of the soundbar and the unit will automatically switch to USB mode and play the first compatible track. USB repeat mode (also accessed via the remote control) enables single track repeat (ONE), all track repeat (ALL). The media player also has a memory function that will recall and continue from the last-played point when a USB flash drive that has previously been used with the soundbar is reinserted.
- **Equalizer modes:** The soundbar has 3 equalizer presets, tailored to complement various styles of music. Press the EQ button on the remote to choose between Music (EQ1), Movie(EQ2), News (EQ3).

Trouble Shooting

ISSUES	PROBLEMS	SOLUTIONS
Sound	No sound from the Soundbar's Speaker.	<p>Connect the audio cable from your soundbar to your TV or other devices. However, you do not need a separate audio connection when the Soundbar and TV are connected through HDMI ARC connection.</p> <p>On the remote control, Select the correct audio input.</p>
	Distorted sound or echo.	If you play audio from the TV through the soundbar, make sure that the TV is muted.
BT	A device cannot connect with the soundbar.	Restart the Soundbar and try pairing again.
		<p>You have not enabled the Bluetooth function of the device. See the user manual of the device on how to enable the function.</p>
		The device is not correctly connected.
		<p>The Soundbar is already connected with another Bluetooth device Disconnect the connected device, then try again.</p>
	Quality of audio play from a connected bluetooth device is poor.	<p>The Bluetooth reception is poor. Move the device closer to the soundbar or remove any obstacle between the device and the soundbar.</p>
The connected bluetooth device connects and disconnects constantly.	<p>The Bluetooth reception is poor. Move the device closer to the soundbar or remove any obstacle between the device and the soundbar.</p>	

