




1400ML MINI DEHUMIDIFIER

MODEL NO: PM400



SCAN ME





INSTRUCTION MANUAL

⚠ WARNING!

Ensure that all safety precautions are followed when using electrical appliances for the proper operation of the device. This instruction booklet describes the safety precautions to be observed during operation to prevent injuries to yourself, other persons and damage to the device. The content not only is suitable for this product but also suitable for electrical appliances in general

Do Not Use This Mini Dehumidifier Until You Have Read This Entire Manual Thoroughly and Keep in a safe place for future reference.

SYMBOLS EXPLAINED

| | | | |
|--|--|---|--|
|  | For indoor use only. |  | Please read instruction manual and retain for future use. |
|  | Equipment complies with the applicable UK safety requirements and regulations. |  | Equipment complies with the applicable EU safety requirements and regulations. |

THANK YOU

F O R B E I N G O U R C U S T O M E R

Thank you for purchasing the innovative product the
PureMate 1400ML Mini Dehumidifier
We wish you many years of healthy air with this efficient and
effective product.


SAFETY PRECAUTIONS

Ensure that all safety precautions are followed when using electrical appliances for the proper operation of the device. This instruction booklet describes the safety precautions to be observed during operation to prevent injuries to yourself, other persons and damage to the device. The content not only is suitable for this device but also suitable for electrical appliances in general.


- The appliance is only to be used with the power supply unit provided with the appliance.
- The appliance is used indoor excluding laundry rooms.
- To avoid electric shock, do not open. There are no serviceable parts inside.
- Do not use around heated surfaces, open flames or flammable substances.
- Do not immerse in water or other liquids.
- Do not use the appliance for any other purpose than its intended use, as described in the manual.
- Keep the inlet and outlet grills clear at all times, do not cover with clothing, plastic bags, etc.

- After you have finished using the home dehumidifier, turn off the dehumidifier.
- Avoid using the mains power adapter in wet or damp places. Position the units in areas where ventilation is good.
- If the supply cord is damaged, it must be replaced, please contact the manufacturer.
- Always keep the unit in an up-right position to avoid water leakage.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance
- The ambient temperature is too low, if it is lower than 15C⁰ , the condensate of the dehumidifier will freeze and frost. At this time, just shut down and stop working, and the machine will not be affected. Generally, dehumidification is not required in low temperature environment.




COMPONENTS




CONTROL PANEL



OPERATING INSTRUCTIONS

- Connect one end of the power cord to the interface on the back of the machine, and the other end to the power socket, that is, the machine enters the standby state. (Figure 1)
-  Press the power button, the home dehumidifier will begin to operate, the power indicator will illuminate. To switch off the unit, press the power switch again.
-  Press the Ambient Light Button to cycle through to change brightness or to turn off.
-  Press the Timer Setting button to set the time for 8/16/24hours/Off. Once the time is over, the dehumidifier will stop working automatically.



WATER TANK FULL INDICATOR

- When the water tank has reached its maximum capacity, the dehumidifier will stop working and ambient light will illuminate red which indicating that the water tank is full. Empty the water tank.

REMOVING THE WATER TANK

- To remove the water tank, first switch off the dehumidifier. Then remove the water tank by holding both sides of the water tank.
- Pour the water into a sink or drain.
- Place the water tank back in to the dehumidifier. Press the power button to continue the dehumidifying process.

CLEANING & MAINTENANCE

Before cleaning the unit, turn off the dehumidifier and unplug the AC/DC adapter first.

- Use a soft cloth to clean the surface of the unit. DO NOT immerse in liquid.
- Use a soft bristled brush to remove dust from the air inlet & outlet.
- It is recommended to clean the filter once a month, wash the filter with water, or use a vacuum cleaner or a dry brush to clean the filter.

IMPORTANT: The water tank cover is detachable for cleaning purposes only.

- Dispose of the collected water and rinse and wipe the inside of the tank.
- After cleaning, place the float back into the water tank and replace the cover.

WARRANTY & SERVICE



The product is covered with PureMate product and labour warranty for 12 months from the date of its original purchase. If any problems occur, please contact the PureMate Customer Care Centre in your country via the contact information listed in this User Guide. We can only provide after sales service for products that are sold by PureMate or PureMate authorized retailers and distributors. If you have purchased your unit from a different place, please contact your seller for return and warranty issues.

SPECIFICATION

| | |
|---------------------|---|
| Model | : PM400 |
| Power Supply | : Input AC100-240V, 50/60Hz Output: 9V DC/2.5A |
| Power | : 22.5W |
| Moisture Removal | : 250-350mL per 24 hours (at test conditions 85% RH,30°C) |
| Cooling Element | : Thermo-electric Peltier Module |
| Water Tank Capacity | : 1400ml |
| Working Environment | : 15°C-40°C, Humidity Below 95% |
| Certifications | : UKCA, CE, Rohs |
| Item Dimensions | : 14.5x14.5x27.4cm |
| Item Weight | : 1.3 Kg |

RECYCLING AND DISPOSAL

Do not dispose of electrical or electronic equipment, batteries, or packaging with regular household waste. Proper disposal helps protect the environment, safeguards health, and preserves natural resources. Items with a plug, battery, or cable are usually recyclable. For disposal options, check with your local council, waste facility, or the store where you bought the item.

| | | |
|--|---|---|
|  | Waste Electrical and Electronic Equipment (WEEE) | This symbol on the product and/or packaging indicates that Waste Electrical product (WEEE) under Directive 2012/19/ EU which governs used electrical and electronic appliances, should not be disposed of with general household waste. |
|  | The Mobius Loop | Recycling Symbol This symbol shows that the product or its packaging can be recycled. |

Battery and Bulb Disposal

Before disposal, remove used batteries and bulbs and place them in appropriate recycling points. Many supermarkets and recycling centers offer dedicated bins for battery collection.

FIND US ONLINE





1400ML MINI DEHUMIDIFIER | MODEL NO: PM 400

Super Tech Health Limited
129 Shady Lane
Great Barr
Birmingham
West Midlands
B44 9ER
United Kingdom

WWW.PUREMATE.CO.UK

© Copyright 2025