

**LED POD**

STL2PDL



## **2-INCH LED POD LIGHT**

### **User Manual**

## BOX CONTENTS

- ◆ Two (2) LED Pod lights
- ◆ Two (2) 18-inch harness with Deutsch connectors
- ◆ Two (2) Stinger Black-out covers
- ◆ Two (2) Amber lens covers
- ◆ Two (2) Pod light mounting brackets
- ◆ Mounting hardware

## FEATURES


- ◆ Trail-ready compact design
- ◆ High-output LED light engine
- ◆ Durable HEXCORE aluminium housing
- ◆ Spot beam pattern
- ◆ White or Amber halo backlit
- ◆ Weather-sealed design for harsh environments
- ◆ Universal mounting system

## TECHNICAL SPECIFICATIONS

- ◆ Operating Voltage: 9-32V DC
- ◆ Light Source: High-intensity LEDs
- ◆ Material Housing: Die-cast aluminium
- ◆ Material Lens: Polycarbonate
- ◆ Ingress Protection: IP69
- ◆ Operating Temperature: -40°F to 140°F(-40°C to 60°C)


## REQUIRED TOOLS

- 13mm wrench or 13mm socket and ratchet
- Number 3mm Allen wrench
- Wire crimper's or cutters





## WIRING

PIN	WIRE COLOR	FUNCTION	VEHICLE WIRING
PIN 1	Red	Hi beam power	External 12V switch
PIN 2	Black	Ground	Chassis ground
PIN 3	N/C	No connection	No connection
PIN 4	Green	Low beam switch	External 12V switch
PIN 5	White	White halo	External 12V switch
PIN 6	Yellow	Amber halo	External 12V switch



Connector is shown from the wire side










## DIMENSIONS



# Installation Guide

## MOUNTING HARDWARE


- Two (2) Mounting brackets
- Two (2) Rubber spacers
- Four (4) M5 X 14mm black oxide bolts
- Four (4) M5 Rubber washers
- Four (4) Lock washers
- Two (2) M8 X 25mm black oxide bolts
- Two (2) M8 Flat washers
- Two (2) M8 Lock washers
- Two (2) M8 Nuts

 Mounting Bracket	 Rubber Spacer	 M5 X 14 BOLT	 M5 RUBBER WASHER	 M5 LOCK WASHER
 M8 X 25 BOLT	 M8 FLAT WASHER	 M8 LOCK WASHER	 M8 NUT	

- Choose a secure, vibration-free mounting surface (bumper, roof rack, A-pillar, etc.).
- Ensure the lights do not obstruct airflow, visibility, or vehicle components.
- Attach the mounting brackets to the pod light.
- Loosely secure hardware to allow for beam adjustment.
- Mount the assembly to the vehicle using the provided hardware.

# Installation Guide

- ◆ Connect the red wire to a positive (+) 12V switch for Hi beam.
- ◆ Connect the green wire to a positive (+) 12V switch for Low beam.
- ◆ Connect the black wire to a clean chassis ground.
- ◆ Connect the yellow wire to a positive (+) 12V switch for amber halo.
- ◆ Connect the white wire to a positive (+) 12V switch for white halo.



# Installation Guide

