

DISK 15W LED DOWNLIGHT

Install Guide and Manual



COMPONENTS




EASY INSTALLATION SURFACEMOUNT-JUNCTIONBOX




Turn Power OFF

1. Turn off circuit breaker that provides power to the light switch for the recessed lights.
 • This fixture is compatible with a 4 inch and 6 inch junction box.




Lens

2. Remove the lens by twisting clockwise.



3. Connect the supply wires to the junction box wires using the wire nuts provided.
 • White to white
 • Green to green
 • Black to black



4. Tuck the connected wires inside the junction box.
5. Align junction box with holes on the fixture that correspond to the size (4" or 6").
6. Attach the fixture to the junction box with either short or long screws pending on the junction box (deep or shallow). DO NOT OVER TIGHTEN.



7. Complete the installation by screwing the lens back into place (counter clockwise).



Turn Power ON

8. Turn on circuit breaker and test the light.

WARNING

All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards. Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections. Please review these instructions carefully before proceeding.

WARNING: Risk of fire or electric shock. Do not alter, relocate or remove wiring during installation.

WARNING: Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation

SPECIFICATIONS

Voltage	120V
Wattage	15W
Suitable for Locations Ingress	Damp
Housing	Polycarbonate
Weight	0.39lbs
Warranty	7 years

DISK 15W LED DOWNLIGHT

Install Guide and Manual



COMPONENTS




EASY INSTALLATION RETROFIT INSTALLATION-CAN




Turn Power OFF

1. Turn off circuit breaker that provides power to the light switch for the recessed lights.
2. Locate the housing.
 - Remove previous fixture, fixture may be hot so allow time to cool after turning off power.




Lens

3. Remove the lens by twisting clockwise.




Spring Holder Metric Screws

4. Place the springs into the keyhole slots on the back of the fixture using the Metric screws provided. Using a screwdriver, gently tighten in place.
 - Slot placement should be chosen based on can size (5" or 6").




Wire Nut

5. Connect the supply wires to the TP24 adapter wires using the wire nuts provided.
 - White to white
 - Black to black
 - It is highly recommended that a licensed electrician installs the ground wire to the box, if not already included in your existing can.



TP24 Connector Wire Nut

6. Connect the TP24 adapter to the TP24 connector inside the recessed can.
7. Attach ground wire to the grounding screw located inside the can.



Spring slots

8. Pinch springs and line up trim ring with opening.
9. Hook disk springs into housing.
 - Strong springs. Use caution when compressing springs to fit inside can. Springs can bounce back quickly and cause injury.



10. Push disk into recessed can until secure
11. Complete the installation by screwing the lens back into place (counter clockwise).



Turn Power ON

12. Turn on circuit breaker and test the light.