


 Verbatim™



User Manual / 사용자 매뉴얼 /  
產品手冊 / 产品手册

Model: VAPMI164



---

## **Introduction:**

Thank you for choosing this Verbatim product. Please read this manual carefully prior to use so as to fully understand the product and its correct usage.

---

## **Caution:**


- Do not alter, modify or disassemble the device. There are no user-serviceable parts inside, and incorrect reassembly may result in shock or fire hazard.
  - Do not drop or subject the device to strong mechanical shock. Do not expose to moisture, water, rain, snow, spray, heat, sources of ignition or direct sunlight.
  - Use a damp soft cloth to clean the surface of the case. Do not use chemical solvents.
  - Contact our customer support team if you have troubleshooting issues with this product.
  - Do not operate the device if it has been dropped or otherwise damaged in any way.
- 

## **Package Contents:**

- 1 x Wireless optical mouse
  - 1 x Nano receiver
  - 1 x AA Battery (1200mAh)
  - 1 x User manual
- 

## **Specifications:**

- Product name: Bluetooth 5.0 2.4GHz Wireless Mouse
- Product model: VAPMI164
- Materials: ABS
- Working distance: Max. 10 meter
- Color: Grey
- Dimensions: 109.5 x 61.9 x 39.3(mm) (LxWxH)
- Weight: 66g(mouse) /2g (nano receiver)
- Operating Temperature: 0°C ~ 40°C
- Storage temperature: -20°C ~ 60°C



## Product Features:

- 5 Silent buttons + 1 Scroll button
- Four levels of sensitivity: 800, 1200, 1600, 2400dpi
- Battery : AA
- Bluetooth 5.0 & RF 2.4GHz/16 Channels
- Easy installation and setup
- Sleep mode for power saving (after inactive for 10 seconds)
- Operating systems: Windows 8 / MacOS 10,12 / iPadOS 9 / Android 6 or higher

## First Time Using:

1. Install battery into the battery compartment.
2. Turn on the mouse. The LED indicator will turn red for 2 seconds which shows that the mouse is in 2.4GHz mode.
3. Remove the USB receiver from inside the battery compartment and connect it to the computer's USB-A port.

- 
4. The mouse will automatically connect to the computer and be ready to use.
- 

### **Switching to Bluetooth:**

1. In 2.4GHz mode, press the DPI/Mode Switch for 3 seconds until the LED indicator turns green. This means the mouse is in Bluetooth mode.
  2. When connecting to Bluetooth for the first time, press the Bluetooth pairing button on the bottom. The LED indicator will flash green.
  3. Turn on Bluetooth on your device and select "Add new Bluetooth items". Look for "Verbatim BT Mouse" and choose connect (Refer to the user manual of your connecting device.)
  4. Once Connected, your mouse will be ready to use.
- 

### **Remarks:**

1. The mouse will remember the mode it was in when switched off and will automatically start in the same mode when switched on again.
  2. Switch between Wi-Fi and Bluetooth modes by pressing the DPI/Mode Switch for 3 seconds until the LED indicator comes on. The indicator will be red when in 2.4GHz Wi-Fi mode and green when in Bluetooth mode.
  3. If the mouse has previously been connected via Bluetooth to a different device, press the Bluetooth pairing button again to connect to the new device, then select the mouse via Bluetooth settings on the new device.
  4. When switching between Bluetooth and 2.4GHz Wi-Fi, the Wireless indicator will flash green once and connect to the receiver immediately.
- 

### **Switching Resolution :**

1. You can change the mouse's resolution by pressing the DPI/Mode switch. The LED indicator will flash to indicate the resolution has been changed.
2. If the LED indicator flashes once - it is set at 800dpi  
If the indicator flashes twice- it is set at 1200dpi

- 
- If the indicator flashes 3 times- it is set at 1600dpi  
If the indicator flashes 4 times- it is set at 2400dpi
3. The color of indicator will be in red color under 2.4 GHz mode and green color under Bluetooth mode.
- 

#### **Q&A:**

**Q:** Why isn't my mouse connecting to my device which was previously connected via Bluetooth?

**A:** Check the device's Bluetooth is on. If the mouse has been removed from the device, press the "Bluetooth pairing", the LED indicator will flash green and broadcast the pairing ID.

**Q:** Why isn't my mouse cursor moving as smoothly as it was previously?

**A:** This maybe an indication of low battery level.

 Verbatim.



1 Year Limited Warranty – for further details visit [www.verbatim.com/warranty](http://www.verbatim.com/warranty)

**Verbatim Australia Pty Ltd (ABN 39 005 706 374)**

**• Warranty Statement**

**Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.**

**Verbatim Australia Pty Ltd (ABN 39 005 706 374) (“Verbatim”) provides the following warranty in relation to its goods (“Product”).**

**The benefits of this warranty are in addition to any rights and remedies imposed by Australian State & Federal legislation that cannot be excluded. Nothing in this warranty is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.**

**Verbatim warrants that, subject to the exclusions and limitations below, the Product will be free from defects in materials and workmanship for the period specified on the product packaging and/or the website from date of purchase. If a defect appears in the Product before the end of the warranty period and Verbatim finds the Product to be defective in materials and workmanship, Verbatim will at its own discretion repair or replace the Product free of charge. If goods presented for repair are capable of retaining user-generated data, repair of these goods may result in loss of the data.**

**• Proof of Purchase**

**Proof of purchase shall be required to be eligible for this warranty and to establish the commencement date of this warranty. This warranty is valid for the original purchase only and is not transferrable to a subsequent customer if the Product is sold by the original customer during the warranty period.**

**The term of your warranty period shall commence from the purchase date appearing on your purchase receipt from an authorised distributor, reseller or retailer and extends only for the time set forth in the Product documentation. This information can be obtained from the packaging and/or the Verbatim Australia website.**

**• Returned Merchandise Authorisation**

**No product may be returned to Verbatim Australia without first contacting us for a RMA (Returned Merchandise Authorisation) number. If it is determined that a**

Product may be defective, you will be given an authorisation number and instructions for Product return. An unauthorised return, i.e. one for which an RMA number has not been issued, will be returned to you at your expense. Authorised returns are to be shipped prepaid and insured to our Head Office in qualified packaging.

- **Warranty Claims**

- 1) If a fault covered by warranty occurs, the customer must first:
  - a) Contact Verbatim Australia Head Office using the contact details provided below; or
  - b) Return the Product to the retailer from which the Product was purchased.
- 2) Any warranty claim must be accompanied by:
  - a) Proof of purchase; and
  - b) Full details of the alleged defect.
- 3) If Verbatim or the retailer from which the Product was purchased finds no defect in the Product after inspection and testing, the customer must pay Verbatim's usual costs of service work and testing.
- 4) The customer must bear the cost of the transport to Verbatim or to and from the retailer to make the warranty claim including all insurance of the Product. Verbatim will bear the cost of the return transport to the customer once the claim has been finalised.

- **Exclusions**

The warranty will not apply where:

- 1) The Product has been repaired, altered or modified by someone other than Verbatim or an authorised repair agent;
- 2) The alleged defect in the Product is within acceptable industry variances;
- 3) Verbatim cannot establish any fault in the Product after testing and inspection;
- 4) The Product has been used other than for the purpose for which it was designed;
- 5) The defect in the Product has arisen due to the customer's failure to properly use and maintain the Product in accordance with Verbatim's instructions, recommendations and specifications (including applicable maintenance schedules);
- 6) The Product has been subject to abnormal conditions or use, including environment, temperature, water, fire, humidity, pressure, stress or similar;

- 7) The defect has arisen due to abuse, misuse, neglect or accident.
- The warranty does not extend to:
    - 1) Damage or defects caused by normal wear and tear;
    - 2) General, consequential, punitive, incidental or special damages. These include loss of recorded data, interruption of use, the cost of recovery of lost data, lost profits and the cost of the installation or removal of any Products, the installation of replacement Products, and any inspection, testing or redesign caused by any defect or by the repair or replacement of Products arising from a defect in any Product.
    - 3) Incompatibility or poor performance due to specific computer or hardware used.

- Limitations

Verbatim makes no express warranties or representations other than set out in this warranty.

The replacement of the Product or part of the Product is the absolute limit of Verbatim's liability under this express warranty.

- Contact Details

Verbatim Australia Pty Ltd

Unit 6, 450 Princes Highway, Noble Park, Victoria 3174, Australia

Tel: +61 3 9790 8999 Fax: +61 3 9790 8955

Email: [support@verbatim.com.au](mailto:support@verbatim.com.au)

Website: [www.verbatim.com.au](http://www.verbatim.com.au)

---

## 소개:

버바티م 제품을 선택하여 주셔서 감사합니다. 제품에 대한 이해와 올바른 사용을 위해 사용 전, 이 매뉴얼을 숙지하여 주시기 바랍니다.

---

## 주의:


- 제품을 수리, 수정, 변경하지 마십시오. 내부에는 사용자가 수리할 수 있는 부품이 없습니다. 잘못된 재조립으로 충격이나 화재의 위험이 발생할 수 있습니다.
  - 제품을 떨어뜨리거나 강한 충격을 가하지 마십시오. 제품이 습기, 물, 비, 눈, 스프레이, 열, 발화원, 직사광선에 노출되지 않도록 하십시오.
  - 제품 표면은 부드러운 천으로 닦으십시오. 화학 용제를 사용하지 마십시오.
  - 이 제품에 대한 문의나 문제 해결에 대해서는 고객 지원팀에 연락하시기 바랍니다.
  - 제품을 떨어뜨리거나 손상이 가해졌을 경우에는 작동하지 마십시오.
- 

## 구성품:

- 1 x 무선 마우스
  - 1 x 나노 리시버
  - 1 x AA 배터리(1200mAh)
  - 1 x 사용자 매뉴얼
- 

## 제품사양:

- 제품명: 블루투스 5.0 2.4GHz 무선 마우스
- 모델명: VAPMI164
- 소재: ABS
- 작동거리: 최대 10m
- 컬러: 그레이
- 제품 크기: 109.5 x 61.9 x 39.3(mm) (LxWxH)
- 무게: 66g(마우스) /2g (나노 리시버)
- 작동온도: 0°C ~ 40°C
- 보관온도: -20°C ~ 60°C



1. 앞, 뒤 버튼
2. On/Off 버튼
3. 배터리 커버
4. 페어링 버튼
5. 스크롤휠/중간버튼
6. DPI/모드 스위치#
7. LED 표시등

# DPI 변경 시에는 이 버튼을 짧게, 모드 변경 시에는 길게 누르십시오.

## 제품 특징:

- 5 저소음 버튼 + 1 스크롤 휠
- 4단계 감도: 800, 1200, 1600, 2400dpi
- 배터리: AA
- 블루투스 5.0 및 RF 2.4GHz/16 채널
- 쉬운 설치
- (10초 동안 작동이 없을 시) 슬림 모드 전환으로 전원 절약
- 작동 시스템: Windows 8 / MacOS 10.12 / iPadOS 9 / Android 6 이상

## 첫 사용:

1. 배터리를 배터리칸에 넣습니다.
2. 마우스를 켜면 빨간 LED가 2초간 켜질 것입니다. 이것은 마우스가 2.4GHz 모드임을 의미합니다.
3. 배터리칸 안쪽에 들어있는 USB 리시버를 꺼내서 컴퓨터의 USB-A 포트에 연결합니다.

---

4. 컴퓨터에 마우스가 자동으로 설치되어 사용이 가능합니다.

---

### **블루투스 모드로 사용:**

1. 2.4GHz 모드에서 "DPI/모드"버튼을 LED가 녹색으로 바뀔 때까지 약 3초간 누르십시오. 이것은 마우스가 블루투스 모드로 전환되었음을 의미합니다.
  2. 블루투스로 첫 연결 시, 마우스 아래의 페어링 버튼을 누르면 녹색 LED가 깜빡일 것입니다.
  3. 사용자장치의 블루투스를 켜고, "새로운 블루투스 장치 추가"를 선택합니다. "Verbatim BT Mouse" 선택하여 연결하십시오. (자세한 내용은 버batim마우스를 연결할 장치의 설명서를 참조하십시오.)
  4. 연결되면 마우스 사용이 가능합니다.
- 

### **참고:**

1. 마우스는 꺼질 때 사용된 모드를 기억하므로, 마우스를 다시 켜면 자동으로 마지막으로 사용된 것과 동일한 모드로 켜집니다.
  2. 사용자는 "DPI/모드"를 LED가 켜질 때까지 약 3초간 눌러 Wi-Fi 또는 블루투스 모드로 전환할 수 있습니다. 빨간 LED는 2.4GHz Wi-Fi 모드를, 녹색 LED는 블루투스 모드를 의미합니다.
  3. 어떤 장치에 블루투스로 연결된 적이 있는 마우스를 다른 장치와 연결하실 때는 "블루투스 페어링" 버튼을 눌러 새로운 장치에 마우스를 다시 연결해 주십시오.
  4. 블루투스와 2.4Hz Wi-Fi 모드 전환 시, 무선 표시등이 녹색으로 한 번깜빡이고 즉시 리시버에 연결됩니다.
- 

### **해상도 변경:**

1. "DPI/모드" 버튼을 눌러 해상도를 변경할 수 있습니다. LED가 깜빡이는 횟수로 해상도를 알 수 있습니다.
2. LED 한번 깜빡임 - 800 dpi  
LED 두번 깜빡임 - 1200 dpi

---

LED 세번 깜빡임 - 1600 dpi

LED 네번 깜빡임 - 2400 dpi

3. LED는 2.4GHz 모드에서는 빨간색, 블루투스 모드에서는 녹색입니다.

---

## Q&A:

Q: 마우스가 전에 연결된 적 있는 장치와 연결되지 않습니다.

A: 장치의 블루투스가 켜졌는지 확인하십시오. 마우스가 장치에서 제거된 경우, "블루투스 페어링"을 버튼을 누르면 녹색 LED가 깜빡이며 페어링 ID가 뜰 것입니다.

Q: 마우스가 이전처럼 부드럽게 움직이지 않습니다.

A: 배터리 교환 시기가 되면 이런 현상이 일어날 수 있습니다. 새로운 배터리로 교체해 보시기 바랍니다.

 Verbatim.



1년의 제한된 품질보증 -

보다 자세한 정보는 [www.verbatim.com/warranty](http://www.verbatim.com/warranty)를 참고 하십시오

KO

---

## 前言：

感謝您選購並使用VERBATIM產品，為讓您能夠更好的使用本產品的所有功能，請您在正式使用本產品前，仔細閱讀本手冊內所提及的注意事項以及詳細功能操作說明。

---

## 注意事項：

- 請不要變更，修改或拆開此設備。內部沒有用戶可維修的零件。不正確的拆裝可能會導致觸電或火災。
  - 請不要摔落或讓設備承受強烈的衝擊。請不要將設備暴露在潮濕，水，雨，雪，噴霧，熱或火源的環境。
  - 可用擰乾的濕棉布輕輕擦抹此設備的外殼，嚴禁使用其他化學溶液清洗。
  - 如在使用本產品上遇到任何問題，請聯繫我們的客戶支援團隊。
  - 請勿操作已受損的設備，包括受到摔落或其他形式的損壞。
- 

## 包裝內容：


- 1 x 無線光學滑鼠
  - 1 x Nano 接收器
  - 1 x AA 電池 (1200mAh)
  - 1 x 使用手冊
- 

## 產品規格：

- 產品名稱：藍牙 5.0 2.4GHz 無線滑鼠
- 產品型號：VAPMI164
- 物料：ABS
- 工作距離：最大10米
- 顏色：灰色
- 產品尺寸：109.5 x 61.9 x 39.3(毫米)(LxWxH)
- 產品重量：66克(滑鼠) /2克 (Nano 接收器)
- 工作溫度：0°C ~ 40°C
- 儲存溫度：-20°C ~ 60°C




1. 前進和後退按鈕
2. 開/關鍵
3. 電池蓋



4. 配對按鈕
5. 滾輪/中間按鈕
6. DPI/模式切換#
7. LED指示燈

#注解:

1. 短按切換DPI設定
2. 長按切換模式設定



- 5
- 6
- 7

## 產品特點：

- 5 個靜音按鈕 + 1 個滾動按鈕
- 四段式感應器：800/1200/1600/2400dpi
- 電池: AA
- 藍牙5.0和2.4GHz無線技術/16 通道
- 簡易安裝和設定
- 省電睡眠模式（閒置10秒後啟動）
- 作業系統：Windows 8 / MacOS 10.12 / iPadOS 9 / Android 6 或更高版本

## 第一次使用：

1. 將電池裝入電池格。
2. 開啟滑鼠。指示燈將亮起紅色 2 秒。滑鼠將處於 2.4 GHz 模式。
3. 取出收納在電池格內的USB接收器，插入電腦的USB-A接口。

- 
4. 電腦會自動對滑鼠進行設置，連接成功後即可使用。
- 

#### 切換到藍牙：

1. 在2.4GHz模式下，按住“DPI/模式”按鈕3秒，直到指示燈亮起綠燈。這表示滑鼠處於藍牙模式。
  2. 第一次在電腦上使用，按下底部的藍牙配對按鈕。指示燈將閃爍綠燈。
  3. 打開設備上的藍牙並選擇添加新的藍牙項目。尋找“Verbatim BT Mouse”並選擇連接。（請參考連接設備的用戶手冊）
  4. 滑鼠連接成功後即可使用。
- 

#### 備註：

1. 滑鼠會記憶上次關閉時的模式。它將會啟動與上次使用的相同模式。
  2. 用戶只需按住“DPI/模式”按鈕3秒，直到指示燈亮起，即可在兩種模式之間切換。指示燈亮紅色表示處於 2.4GHz 模式，綠色表示處於藍牙模式。
  3. 如果滑鼠已經通過藍牙連接到一個設備，用戶必須再次按下“藍牙配對”按鈕才能連接到新設備，並需要在設備上再次選擇滑鼠。
  4. 從藍牙切換到2.4GHz，“LED指示燈”綠燈閃爍1次，將立即連接到接收器。
- 

#### 切換分辨率：

1. 改變分辨率 - 用戶可以通過按“DPI/模式”按鈕改變分辨率。指示燈將閃爍表示分辨率已更改。
2. 指示燈閃爍 1 次 - 分辨率為 800dpi  
指示燈閃爍 2 次 - 分辨率為 1200 dpi  
指示燈閃爍 3 次 - 分辨率為 1600 dpi  
指示燈閃爍 4 次 - 分辨率為 2400 dpi
3. 指示燈顏色在2.4GHz模式下為紅色，在藍牙模式下為綠色。

---

常見問題：

問：滑鼠無法連接到我之前連接過的藍牙設備。

答：檢查設備的藍牙是否開啟。如果滑鼠已從設備上卸下，請按“配對按鈕”，指示燈將閃爍綠色並廣播配對 ID。再次從設備連接滑鼠。

問：滑鼠移動不像以前那樣流暢。

答：可能代表電池電量不足。更換新電池並重試。

 Verbatim



1年有限保固 - 詳情請瀏覽 [www.verbatim.com/warranty](http://www.verbatim.com/warranty)

TC

---

## 前言：

感谢您选购并使用VERBATIM产品，为了让您能够更好的使用本产品的所有功能，请您在正式使用本产品前，仔细阅读本手册内所提及的注意事项以及详细功能操作说明。

---

## 注意事项：


- 请不要变更，修改或拆开此设备。内部没有用户可维修的零件。不正确的拆装可能会导致触电或火灾。
  - 请不要摔落或让设备承受强烈的冲击。请不要将设备暴露在潮湿，水，雨，雪，喷雾，热或火源的环境。
  - 可用拧乾的湿棉布轻轻擦抹此设备的外壳，严禁使用其他化学溶液清洗。
  - 如在使用本产品上遇到任何问题，请联系我们的客户支持团队。
  - 请勿操作已受损的设备，包括受到摔落或其他形式的损坏。
- 

## 包装内容：

- 1 x 无线光学鼠标
  - 1 x Nano 接收器
  - 1 x AA 电池 (1200mAh)
  - 1 x 使用手册
- 

## 产品规格：

- 产品名称：蓝牙 5.0 2.4GHz 无线鼠标
- 产品型号：VAPMI164
- 物料：ABS
- 工作距离：最大10米
- 颜色：灰色
- 产品尺寸：109.5 x 61.9 x 39.3(毫米)(LxWxH)
- 产品重量：66克(鼠标) /2克 (Nano 接收器)
- 工作温度：0°C ~ 40°C
- 储存温度：-20C ~ 60°C



### 产品特点：

- 5个静音按钮 + 1个滚动按钮
- 四段式感应器：800/1200/1600/2400dpi
- 电池: AA
- 蓝牙5.0和2.4GHz无线技术/16通道
- 简易安装和设定
- 省电睡眠模式（闲置10秒后启动）
- 作业系统：Windows 8 / MacOS 10.12 / iPadOS 9 / Android 6 或更高版本

### 第一次使用：

1. 将电池装入电池格。
2. 开启鼠标。指示灯将亮起红色2秒。鼠标将处于2.4GHz模式。
3. 取出收纳在电池格内的USB接收器，插入电脑的USB-A接口。

---

4. 电脑会自动对鼠标进行设置，连接成功后即可使用。

---

#### 切换到蓝牙：

1. 在2.4GHz模式下，按住“DPI/模式”按钮3秒，直到指示灯亮起绿灯。这表示鼠标处于蓝牙模式。
  2. 第一次在电脑上使用，按下底部的蓝牙配对按钮。指示灯将闪烁绿灯。
  3. 打开设备上的蓝牙并选择添加新的蓝牙项目。寻找“Verbatim BT Mouse”并选择连接。（请参考连接设备的用户手册）
  4. 鼠标连接成功后即可使用。
- 

#### 备注：

1. 鼠标会记忆上次关闭时的模式。它将会启动与上次使用的相同模式。
  2. 用户只需按住“DPI/模式”按钮3秒，直到指示灯亮起，即可在两种模式之间切换。指示灯亮红色表示处于2.4GHz模式，绿色表示处于蓝牙模式。
  3. 如果鼠标已经通过蓝牙连接到一个设备，用户必须再次按下“蓝牙配对”按钮才能连接到新设备，并需要在设备上再次选择鼠标。
  4. 从蓝牙切换到2.4GHz，“LED指示灯”绿灯闪烁1次，将立即连接到接收器。
- 

#### 切换分辨率：

1. 改变分辨率 - 用户可以通过按“DPI/模式”按钮改变分辨率。指示灯将闪烁表示分辨率已更改。
2. 指示灯闪烁 1 次 - 分辨率为 800dpi  
指示灯闪烁 2 次 - 分辨率为 1200 dpi  
指示灯闪烁 3 次 - 分辨率为 1600 dpi  
指示灯闪烁 4 次 - 分辨率为 2400 dpi
3. 指示灯颜色在2.4GHz模式下为红色，在蓝牙模式下为绿色。

---

常见问题：

问：鼠标无法连接到我之前连接过的蓝牙设备。

答：检查设备的蓝牙是否开启。如果鼠标已从设备上卸下，请按“配对按钮”，指示灯将闪烁绿色并广播配对 ID。再次从设备连接鼠标。

问：鼠标移动不像以前那样流畅。

答：可能代表电池电量不足。更换新电池并重试。

 Verbatim.



1年有限质保 - 详情请访问 [www.verbatim.com/warranty](http://www.verbatim.com/warranty)

SC